

**WISCONSIN
MODEL VG4D**

**REPAIR
MANUAL**

VG4D



CORP.

FOREWORD

Good operation and a planned maintenance program as outlined in this manual are vital in obtaining maximum engine performance and long engine life. The instructions on the following pages have been written with this in mind, to give the operator a better understanding of the various problems which may arise, and the manner in which these problems can best be solved or avoided.

The operator is cautioned against the use of any parts, other than genuine Wis-Con Total Power Corp. parts, for replacement or repair. These parts have been engineered and tested for their particular job, and the use of any other parts may result in unsatisfactory performance and short engine life. Wis-Con Total Power Corp. distributors and dealers, because of their close factory relations, can render the best and most efficient service.

THE LIFE OF YOUR ENGINE DEPENDS ON THE CARE IT RECEIVES.

The MODEL, SPECIFICATION and SERIAL NUMBER of your engine must be given when ordering parts. The MODEL and SPECIFICATION number are on the name plate. The SERIAL NUMBER is stamped either on the crankcase or the engine's identification tag.

Copy the MODEL, SPECIFICATION and SERIAL NUMBER in the spaces provided below so that it will be available when ordering parts.

MODEL

SPECIFICATION

SERIAL NUMBER

To insure prompt and accurate service, the following information must also be given:

1. State EXACTLY the quantity of each part and part number.
2. State definitely whether parts are to be shipped by express, freight or parcel post.
3. State the exact mailing address.

IMPORTANT

READ THESE INSTRUCTIONS CAREFULLY

All points of operation and maintenance have been covered as carefully as possible, but if further information is required, send inquiries to the factory for prompt attention.

When writing to the factory, ALWAYS GIVE THE MODEL, SPECIFICATION AND SERIAL NUMBER of the engine referred to.

Starting and Operating New Engines

Careful breaking-in of a new engine will greatly increase its life and result in troublefree operation. A factory test is not sufficient to establish the polished bearing surfaces, which are so necessary to the proper performance and long life of an engine. These can only be obtained by running a new engine carefully and under reduced loads for a short time.

- Be sure the engine is filled to the proper level with a good quality engine oil.
- For proper procedures to follow when breaking-in a new engine, see 'Testing Rebuilt Engine'.

The various bearing surfaces in a new engine have not been glazed, as they will be with continued operation, and it is in this period of "running in" that special care must be exercised, otherwise the highly desired glaze will never be obtained. A new bearing surface that has once been damaged by carelessness will be ruined forever.

IMPORTANT SAFETY NOTICE

Proper repair is important to the safe and reliable operation of an engine. This Repair Manual outlines basic recommended procedures, some of which require special tools, devices or work methods.

Improper repair procedures can be dangerous and could result in injury or death.

READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND WARNINGS BEFORE PERFORMING REPAIRS ON THIS ENGINE

Warning labels have also been put on the engines to provide instructions and identify specific hazards which, if not heeded, could cause bodily injury or death to you or other persons. These labels identify hazards which may not be apparent to a trained mechanic. There are many potential hazards for an untrained mechanic and there is no way to label the engine against all such hazards. These warnings in the Repair Manual and on the engine are identified by this symbol:



Operations that may result only in engine damage are identified in the Repair Manual by this symbol:



Wis-Con Total Power Corp. cannot anticipate every possible circumstance that might involve a potential hazard; therefore, the warnings in this manual are not all inclusive. If a procedure, tool, device or work method not specifically recommended by Wis-Con Total Power Corp., Industrial Product Division is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the engine will not be damaged or made unsafe by the procedures you choose.

IMPORTANT: The information, specifications and illustrations in this manual are based on information that was available at the time it was published. The specifications, torques, pressures of operation, measurements, adjustments, illustrations and other items can change at any time. These changes can affect the service given to the product. Get the complete and most current information before starting any job. For parts, service, or information, contact Wis-Con Total Power Corp., Memphis, Tennessee.

WARNING

Most sub-systems used in conjunction with Wis-Con Total Power Corp. industrial engines including (but not limited to) radiators, hoses, fans, fuel tanks, fuel lines or other fuel system components, batteries, electrical connections or other electrical components, clutches, transmissions, hydraulic pumps and generators, are not supplied by Wis-Con Total Power Corp. These items are provided by the manufacturer of the end item in which the engine is used.

Some of the dangers associated with servicing such items are generally mentioned in this manual; however, the appropriate handbooks and safety instructions provided by the manufacturer of the end item should always be consulted prior to the undertaking of any work on sub-systems attached to the engine, to avoid any hazards inherent to these sub-systems.

WARNING

Read and observe all individual safety warnings as you use this manual to operate, service or repair your engine.

Always exercise caution whenever working with an engine or any associated system.

Injuries may be caused by lack of care when working with, or near, moving parts, hot parts, pressurized systems, electrical equipment, or fuel systems.

Always wear eye and hearing protection when working on or near engines.

Improper attire such as loose clothing, ties, rings, soft shoes or bare feet could be hazardous and should be avoided when servicing engines.

Use or service of the engine (including the use of modified parts or materials) not in accordance with manufacturer's specifications could damage your engine or cause personal injury.

WARNING

Some equipment and materials used in the overhaul or maintenance of an engine such as machine tools, electrical equipment, compressed air, solvents, gasoline or other fuels may be dangerous and can cause injury. Always observe safety precautions.

SAFETY PRECAUTIONS

- Never fill fuel tank while engine is running or hot; avoid the possibility of spilled fuel causing a fire.
- Always refuel slowly to avoid spillage.
- When starting engine, maintain a safe distance from moving parts of equipment.
- Do not start engine with clutch engaged.
- Do not spin hand crank when starting. Keep cranking components clean and free from conditions which might cause the crank jaw to bind and not release properly. Oil periodically to prevent rust.
- Never run engine with governor disconnected, or operate at speeds in excess of 2400 R.P.M. load.
- Do not operate engine in a closed building unless the exhaust is piped outside. This exhaust contains carbon monoxide, a poisonous, odorless and invisible gas, which if breathed causes serious illness and possible death.
- Never make adjustments on machinery while it is connected to the engine, without first removing the ignition cable from the spark plug. Turning the machinery over by hand during adjusting or cleaning might start the engine and machinery with it, causing serious injury to the operator.
- Precaution is the best insurance against accidents.


*Keep this book handy at all times,
familiarize yourself with the operating instructions.*

Model VG4D


3-1/2" Bore — 4" Stroke
154 cu. in. Displacement

CONTENTS

Accessories — Service Instructions	29	Horsepower	7
Fuel Pump, Flywheel Alternator, Carburetor, Magneto, Solid State Ignition Distributors		Ignition Switch	8
Air Cleaners and Pre-Cleaner	I0	Ignition System	7
Battery Ignition — Wiring and Timing Diagram	I3	Illustration of Engine and Power Unit	4
Carburetor Adjustment	11	Lubrication	7
Carburetor Service	37	Lubrication System	7
Zenith Model 87A8	37	Lubrication System — Illustration	6
Charging System	15	Magneto Breaker Point Adjustment	11
Clutch Power Take-Off	25	Magneto Ignition Spark	11
Clutch Adjustment	25	Magneto Service	39
Clutch Reduction Units	26	Fairbanks-Morse type FM-X4B7A	40
Compression — Restoring	15	Wico Model XHG-4	39
Cooling	7	Magneto Timing Diagram	12
Disassembly and Reassembly	18	Magneto Timing	12
Air Shrouding	19	Neon Lamp Timing	14
Camshaft	24	Oil Filter	9
Camshaft Gear	20	Oil — Grade of	8
Carburetor and Manifold	19	Oil Pressure	8
Crankshaft (End Play)	23	Overheating, Keep Engine Clean	15
Cylinder Block	22	Reduction Gears	26
Cylinder Head	20	Rotation	7
Flywheel	19	Safety Notice	ii-iii
Fuel Tank	19	Safety Precautions	2
Gear Cover	20	Safety Switch — High Temperature	15
Idler Gear and Shaft	20	Solid State Ignition	13, 41
Oil Pan	21	Spark Plugs	15
Oil Pump	21	Starting and Operating Instructions	7
Piston, Ring and Rod Clearance Chart	23	Starting and Operating New Engine	i
Piston Rings	22	Starting Procedure	9
Pistons and Connecting Rods	21	Stopping Engine — Vapor Lock and Dieseling	9
Valves and Seat Inserts	23	Storage of Engine	26
Distributor — Battery Ignition	13	Testing Rebuilt Engine	18
Distributor and Generator Maintenance	14	Troubles — Causes and Remedies	16
Distributor Timing	13	Backfiring Through Carburetor	18
Electrical Wiring Diagram	13	Compression	17
Engine Sectional Views	5	Engine Stops	18
Firing Order	15	Ignition	17
Flywheel Alternator with Solid State Regulation	31	Knocking	18
Fuel	8	Missing	17
Fuel Pump and Priming	8	Overheating	18
Fuel Pump Service	30	Starting Difficulties	17
Gasoline Strainer	11	Surging or Galloping	18
General Information and Design	7	Valves — Grinding and Tolerances	23
Governor Adjustment	24	Valve Tappets	24
Hot Weather Operation	16	Warm-Up Period — Overspeeding	9



OPEN ENGINE - TAKE-OFF VIEW




POWER UNIT - LEFT HAND SIDE VIEW

Fig. 1


MODEL VG4D OPEN ENGINE AND POWER UNIT

CROSS SECTION OF MODEL VG4D ENGINE

Fig. 2



LUBRICATION SYSTEM
Fig. 3



WITH ENGINE AT OPERATING TEMPERATURE, OIL PRESSURE IN HEADER WILL BE APPROXIMATELY 5 POUNDS. AN OIL PRESSURE GAUGE IS NOT REQUIRED.

GENERAL INFORMATION and DESIGN

Wisconsin engines are of the **four cycle type**, in which each of the four operations of **intake, compression, expansion and exhaust** requires a complete stroke. This gives one power stroke per cylinder for each two revolutions of the crankshaft.

COOLING

Cooling is accomplished by a flow of air, circulated over the cylinders and heads of the engine, by a combination fan-flywheel encased in a sheet metal shroud. The air is divided and directed by ducts and baffle plates to insure uniform cooling of all parts.

Never operate an engine with any part of the shrouding removed – this will retard air cooling.

Keep the cylinder and head fins free from dirt and chaff. Improper circulation of cooling air will cause engine to overheat.

CARBURETOR

The proper combustible mixture of gasoline and air is furnished by a balanced carburetor, giving correct fuel to air ratios for all speeds and loads.

IGNITION SYSTEM

The spark for ignition of the fuel mixture is furnished by a high tension magneto driven off the timing gears at crankshaft speed. The magneto distributor rotor turns at half-engine speed. The magneto is fitted with an impulse coupling, which makes possible a powerful spark for easy starting. Also, the impulse coupling automatically retards the spark for starting, thus eliminating possible kick back from engine while cranking.

Battery ignition (12 volt) distributor is furnished in place of magneto on engines equipped with flywheel alternator or belt driven generator. See Page 13.

LUBRICATION SYSTEM (Fig. 3)

A gear type pump supplies oil to four nozzles which direct oil streams against fins on the connecting rod caps. Part of the oil enters the rod bearing through holes in the rods, and the balance of the oil forms a spray of mist which lubricates the cylinder walls and other internal parts of the engine. An external oil line from the oil header tube in the crankcase lubricates the governor and gear train.

GOVERNOR

A governor of the centrifugal flyweight type maintains the engine speed by varying the throttle opening to suit the load imposed upon the engine. These engines are equipped with either a **fixed speed** governor, a **variable speed control** to regulate the governed speed of the engine, or an **idle control**.

ROTATION

The rotation of the crankshaft is clockwise when viewing the flywheel or cranking end of the engine. This gives **counter-clockwise rotation** when viewing

the power take-off end of the crankshaft. The flywheel end of the engine is designated the **front end**, and the power take-off end, the **rear end** of the engine.

R.P.M.	VG4D HORSEPOWER
1400	25
1600	29
1800	32
2000	34
2200	36
2400	37

HORSEPOWER

Horsepower specified in the accompanying chart is for an atmospheric temperature of 60° Fahrenheit at sea level and at a Barometric pressure of 29.92 inches of mercury.

For each inch lower the Barometric pressure drops, there will be a loss in horsepower of 3½%.

For each 10° temperature rise there will be a reduction in horsepower of 1%.

For each 1000 ft. altitude above sea level there will be a reduction in horsepower of 3½%.

The friction in new engines cannot be reduced to the ultimate minimum during the regular block test, but engines are guaranteed to develop at least 85 per cent of maximum power when shipped from the factory. The power will increase as friction is reduced during the first few days of operation. The engine will develop at least 95% of maximum horsepower when friction is reduced to a minimum.

For continuous operation, allow 20% of horsepower shown as a safety factor.

STARTING and OPERATING INSTRUCTIONS

Engines that are enclosed in a sheet metal house, as shown in bottom view of Fig. 1, are called **power units**. Others are furnished without a house, as shown in top view of Fig. 1, and are called **open engines**.

On engines with a house, the side doors must always be removed when operating.

This is necessary for circulating sufficient air for cooling the engine.

LUBRICATION

Before starting a new engine, fill the oil base with good "gasoline engine" oil, as specified in the "Grade of Oil" chart. Fill through the breather tube shown in Fig. 3, with 5 quarts of oil.

For **run-in of new engines**, use same oil as recommended in *Grade of Oil Chart*.

After the engine has been run for a short time, the oil lines and oil filter will have been filled with oil. Shut off the engine and check the oil level by means of **dip stick** (oil gauge saber). If necessary, add enough oil to bring level up to the **full mark**. The standard dip

GRADE OF OIL

SEASON OR TEMPERATURE		GRADE OF OIL
Spring, Summer or Fall + 120°F to + 40°F		SAE 30
Winter + 40°F to + 15°F + 15°F to 0°F Below Zero		SAE 20-20W SAE 10W SAE 5W-20
Use Oils classified as Service SE, SF, SG or CC		
Crankcase Capacity	New engine	5 Qts.
	Oil and filter change	5 Qts.
	Less - filter or filter change	4½ Qts.

stick location is below the oil filler-breather tube, but can be located on starting motor side upon request.

Use only high-grade highly refined oils, corresponding in body to the S. A. E. (Society of Automotive Engineers) Viscosity Numbers in *Grade of Oil Chart*.

SERVICE CLASSIFICATION OF OIL

In addition to the S.A.E. Viscosity grades, oils are also classified according to severity of engine service. Use oils classified by the Americal Petroleum Institute as **Service SE, SF or SG**. These types of oil are for engines performing under unfavorable or severe operating conditions such as: high speeds, constant starting and stopping, operating in extreme high or low temperatures and excessive idling.

Follow summer recommendations in winter if engine is housed in warm building.

Check oil level every 8 hours of operation.

The old oil should be drained and fresh oil added after every 50 hours of operation.

To drain oil, remove drain plug illustrated in *Fig. 3*. Oil should be drained while engine is hot, as it will then flow more freely.

OIL PRESSURE

At engine operating temperature, the oil pressure will be about 4 to 5 pounds per square inch, and due to this low pressure system, an oil pressure gauge is not required. When the engine is cold the pressure will be higher, and a relief valve is fitted to the oil pump so that under these conditions the maximum pressure will be limited to 15 pounds.

FUEL

These engines can be furnished with either a gravity feed tank mounted above the carburetor fuel level, a side mount tank, or tank mounted below the engine. In the latter two cases, a fuel pump is furnished.

The fuel tank should be filled with a *good quality* gasoline free from dirt and water. The capacity of the tank is approximately 9 gallons. Some of the poorer grades of gasoline contain gum which will deposit on valve stems, piston rings, and in the various small passages in the carburetor, causing serious trouble in operating and in fact might prevent the engine from operating at all.

Use only reputable, well known brands of REGULAR GRADE gasoline.

The gasoline should have an octane rating of at least 90. Low octane gasoline will cause the engine to detonate, or *knock*, and if operation is continued under this condition, cylinders will score, valves will burn, pistons and bearings will be damaged, etc.

Be sure that air vent in tank cap is not plugged, as this would prevent fuel from flowing to the carburetor.

FUEL PUMP and PRIMING (Fig. 4)

The diaphragm type fuel pump, furnished on engines with side mount or underslung fuel tanks, is actuated by an eccentric on the camshaft, as illustrated in cross section of engine, *Fig. 2*.

Hand Primer for *hand crank engine* is an accessory furnished only upon request, and is a necessary function when starting a new engine for the first time, or when engine has been out of operation for a period of time. Gravity feed and electric start engines do not require hand priming.

When priming, a distinct resistance of the fuel pump diaphragm should be felt when moving the hand lever up and down. If this does not occur, the engine should be turned over one revolution so that the fuel pump drive cam will be rotated from its upper position which prevents movement of the pump rocker arm.

Assuming the gasoline strainer is empty, approximately 25 strokes of the primer lever are required to fill the bowl. *See Fig. 4*. After strainer bowl is full, an additional 5 to 10 strokes are required to fill the carburetor bowl. When carburetor is full the hand primer lever will move more easily.

IGNITION SWITCH

Magneto ignition is standard on this engine, with a lever type switch on the side of the magneto, which is always in the *on* or running position, except when depressed for stopping engine. *See top view, Fig. 1*.




Fig. 4

On power unit engines, a push button ignition switch is mounted on the outside of the house panel at the flywheel end. See bottom view of Fig. 1. When starting engine, the ignition switch button is *pulled out*. To stop, *push in*. This will apply to both *magneto* and *battery ignition* systems.

STARTING



Caution: Maintain a safe distance from moving parts of equipment. Know how to stop the engine quickly in case of emergency.



Caution: Do not operate engine in a closed building unless it is properly ventilated.

STARTING PROCEDURE

1. Check crankcase oil level and gasoline supply. Open fuel shut-off valve in fuel strainer or tank.
2. Disengage clutch, if furnished.
3. Pull variable speed control "T" handle out about half-way and lock in place. With a two speed control, start in full load position—idle after engine starts.
4. Close choke by pulling choke button to extreme out position.
5. Pull out ignition switch button, tag reads '*To Stop Push In*'.
6. Depress starter switch to start engine.

IMPORTANT:

Do not crank engine for more than 30 seconds at a time if engine fails to start, wait about 2 minutes between cranking periods to prevent starter from over-heating.

7. After engine starts, push choke button in gradually as required for smooth running. Choke must be completely open (button in) when engine is warmed up.

If flooding should occur, open choke fully by pushing choke button in and continue cranking. Less choking is necessary in warm weather or when engine is warm, than when cold.

WARM-UP PERIOD

The engine should be allowed to warm up to operating temperature before load is applied. This requires only a few minutes of running at moderate speed. **Racing an engine or gunning it**, to hurry the warm-up period, is **very destructive** to the polished wearing surfaces on pistons, rings, cylinders, bearings, etc., as the proper oil film on these various surfaces cannot be established until the oil has warmed up and become sufficiently fluid. This is especially important on new engines and in cool weather.

Racing an engine by disconnecting the governor, or by doing anything to interfere with the governor controlled engine speed, is **extremely dangerous**. The governor is provided as a means for controlling the engine speed to suit the load applied, and also as a safety measure to guard against excessive speeds, which not only overstrain all working parts, but which might cause wrecking of the engine and possible injury to bystanders.

All parts of the engine are designed to safely withstand any speeds which might normally be required, but it must be remembered that the stresses set up in rotating parts, increase with the square of the speed. That means that if the speed is doubled the stresses will be quadrupled; and if the speeds are trebled, the stresses will be nine times as great.

Strict adherence to the above instructions cannot be too strongly urged, and greatly increased engine life will result as a reward for these easily applied recommendations.

STOPPING ENGINE

Magneto ignition engines, less house, have a lever type stop switch on the side of the magneto. On these, **to stop engine**, depress lever and **hold down until engine stops**.

Power units and battery ignition engines, are furnished with an ignition switch, "*To Stop Push In*".

If the engine has been running hard and is hot, do not stop it abruptly from full load, but remove the load and allow engine to run idle at 1000 to 1200 R.P.M. for three to five minutes. This will reduce the internal temperature of the engine much faster, minimize valve warping, and of course the external temperature, including the manifold and carburetor will also reduce faster, due to air circulation from the flywheel.

Two main troubles resulting from abruptly shutting off a hot engine are **vapor lock** and **dieseling**. Vapor lock will prevent the flow of fuel in the fuel lines and carburetor passages, which will result in hard starting. This can be overcome by choking the engine when cranking, or waiting until the engine has cooled off.

Dieseling, is caused by the carbon and lead deposits in the cylinder head being heated up to such an extent that they continue to fire the engine and keep it running after the ignition has been shut off. By idling the engine for a few minutes the carbon and lead deposits cool off, break up, and will blow out thru the exhaust. If engine has a tendency to diesel, by suddenly setting the throttle wide open and at the same time shutting off the ignition, the engine will stop.

MAINTENANCE

OIL FILTER

A **by-pass** type oil filter is furnished on these engines, as shown in Fig. 3, except in a few cases where the use of other accessories prevents the mounting of an oil filter. The **oil filtering cartridge should be replaced after every other oil change**. If operating conditions are **extremely dusty**, replace cartridge after **every oil change**.

AIR CLEANERS

The air cleaner is an essential accessory, filtering the air entering the carburetor and preventing abrasive dirt from entering the engine and wearing out valves and piston rings in a very short time.

The air cleaner must be serviced frequently, depending on the dust conditions where engine is operated. Check hose connections for leaks or breaks; replace all broken or damaged hose clamps.

Excessive smoke or loss of power are good indications the air cleaner requires attention.

The oil bath type air cleaner, illustrated in Fig. 5 is standard equipment on power units. On open engines, the oil bath air filter furnished is illustrated in Fig. 6. A dry element air cleaner is optionally available for both power unit and open engine.

OIL BATH AIR CLEANER (Fig. 5)

Service daily or twice a day; if engine is operating in very dusty conditions. **Once each week**; in comparatively clean conditions.

Remove oil cup from bottom of air cleaner and clean thoroughly. Add fresh oil to the *level line* indicated on cup, using the same grade oil as used in engine.

Operating the engine under dusty conditions without oil in the air cleaner or with dirty oil, may wear out cylinders, pistons, rings and bearings in a few days time, and result in costly repairs.

Once a year; or oftener in very dusty conditions, the air cleaner should be removed from the engine and the element, which is not removable, should be washed in a solvent to clean out accumulated dust and dirt.

DRY ELEMENT AIR CLEANER

Service daily; squeeze rubber duct unloader once or




Fig. 6

twice a day to check for possible obstruction. If engine is operating in very dusty conditions, remove cartridge and shake out accumulated dirt.

Once each week; the filtering cartridge should be taken out and either dry-cleaned with compressed air or washed by repeated dipping for several minutes in a solution of lukewarm water and a mild *non-sudsing* detergent. Rinse in cold water from the inside out and allow to dry overnight before installing.

Do not use gasoline, kerosene or solvent for cleaning. - Do not oil element.

After ten washings or one year of service, whichever comes first, replace cartridge.

PRE-CLEANER (Fig. 6)

The collector type pre-cleaner, mounted to the top of the air cleaner, removes the larger dirt and dust particles before the air reaches the main air cleaner.

Daily; clean bowl of accumulated dust and dirt. *Do not use oil or water in pre-cleaner. This must be kept dry.*




Fig. 5




Fig. 7

GASOLINE STRAINER

The gasoline strainer is very necessary to prevent sediment, dirt and water from entering the carburetor and causing trouble or even complete stoppage of the engine. This strainer has a glass bowl and should be inspected frequently, and cleaned if dirt or water are present. To remove bowl, first shut off fuel valve, then loosen the knurled nut below bowl and swing the wire bail to one side. After cleaning bowl and screen, reassemble the parts, being sure the gasket is in good condition; otherwise use a new gasket. See Fig. 7, which shows the gasoline strainer mounted to the fuel tank of a power unit. On open engines, the strainer is mounted to the inlet of the fuel pump.

CARBURETOR ADJUSTMENT

The main metering jet in the carburetor is of the fixed type, that is, it requires no adjustment. The idle needle should be adjusted for best low speed operation, while carburetor throttle is closed by hand. For more information, see Carburetor Service Instructions in back of this book.

MAGNETO BREAKER POINT ADJUSTMENT

Magnetos are properly adjusted before leaving the factory. The *breaker points* on the Fairbanks-Morse magneto and on the Wico magneto should be .015" at full separation. If the spark becomes weak after continued operation, it may be necessary to readjust these points. To do this, first remove the end cover on the magneto. The crankshaft should then be rotated with the starting crank, (this also rotates the magneto), until the breaker points are wide open. The opening or gap should then be measured with a feeler gauge as shown in Fig. 8 and if necessary reset. To readjust points, first loosen the *locking screws* on the contact plate enough so that the plate can be moved. Insert the end of a small screw driver into the *adjusting slot* at the bottom of the *contact plate* and





Fig. 8



OPEN END VIEW OF FAIRBANKS-MORSE MAGNETO

Fig. 9

open or close the contacts by moving the plate until the proper opening is obtained, see Fig's. 8 and 9. After tightening the locking screws, recheck breaker point gap to make sure it has not changed. If it is found that the breaker points have become pitted or rough, they should be smoothed with a breaker point file before the above adjustments are made. Replace magneto end cover carefully so that it will seal properly. Do not force cover screws too tightly, otherwise cover may crack. For further information, see Fairbanks-Morse or Wico Magneto Maintenance Instructions in back of this book.

MAGNETO IGNITION SPARK

If difficulty is experienced in starting the engine or if engine misses firing, the strength of the ignition spark may be tested by removing the ignition cable from the spark plug and holding the terminal 1/8 inch




Fig. 10




Fig. 11, MAGNETO TIMING DIAGRAM

away from the cylinder head shroud or any other metal part of the engine, as shown in *Fig. 10*. Turn the engine over slowly by the starting crank, two complete revolutions, and watch for the spark discharge which should occur during the cycle, at the instant the impulse coupling on the magneto snaps. Repeat this check with each of the other ignition cables. If there is a weak spark, or none at all, check breaker point opening as mentioned in preceding paragraph under 'Magneto Breaker Point Adjustment'. If this does not remedy the trouble, it may be necessary to install a new condenser. See Magneto Manufacturer's Maintenance Instructions in back of this book.

MAGNETO TIMING

The magneto is properly timed to the engine at the factory, but if for any reason it is necessary to re-time the magneto, the following instructions will be helpful.

First, remove the screen over the flywheel air intake opening by taking out the screws holding the screen in place. This will expose the *timing marks* on flywheel and shroud for timing magneto. See *Fig. 11*.

Next, remove the spark plug from No. 1 cylinder and turn the engine over slowly by the starting crank, at the same time holding a finger over the spark plug hole, so that the compression stroke can be determined by the air blowing out of the hole.

The flywheel is marked with the letters 'DC' near

one of the air circulating vanes. This vane is further identified by an 'X' mark cast on the end. See *Fig. 11*. When the air blows out of the No. 1 spark plug hole, continue turning the starting crank until the edge of the *marked vane* on flywheel is on line with the *mark* on the *vertical centerline* of the *shroud* as shown on *Fig. 11*. Leave flywheel in this position. At this point the *keyway* for mounting the flywheel is also on top.

Next, remove the inspection hole plug from the magneto timing opening, located in the gear cover as shown in *Fig. 10*.

Assuming that the magneto has been removed from the engine, the following procedure should be followed before replacing magneto.

The Number 1 cylinder firing position of the magneto must be determined. Insert the ignition cable into the No. 1 tower terminal of the magneto end cap and hold the spark plug terminal at the other end, about 1/8" away from the magneto body. Turn the magneto gear in a clockwise rotation, tripping the impulse coupling, until the No. 1 terminal sparks, then hold the gear in this position. Mount the magneto to the engine, meshing the gears so that when the magneto is in place, the gear tooth marked with an 'X' will be visible through the *lower half* of the *inspection hole* in the gear cover. See *Timing Diagram, Fig. 11*. Tighten the nut and capscrew for mounting the magneto to the gear cover, making sure the magneto




Fig. 12, BATTERY IGNITION - WIRING AND TIMING DIAGRAM

flange gasket is in place.

No. 1 terminal is identified on the magneto cap. The other terminals follow the firing order of **1-3-4-2** in a clockwise direction viewing cap end. Leads from magneto should be connected to spark plugs of corresponding numbers, see "Firing Order" paragraph.

When magneto is properly timed the impulse coupling will snap when '**DC**' - '**X**' marked vane of flywheel lines up with the **mark** on flywheel shroud, which indicates the **centerline** of the No. 1 and 3 cylinders. This can be checked by turning crankshaft over slowly by hand. The impulse will also snap every 180° of flywheel rotation thereafter.

The **spark advance** is 23°. To check timing with a **neon light**, the running spark advance is indicated by a 1/8" diameter hole on the flywheel shroud, 23° or 3-7/16 inches, before **centerline** of the No. 1 and 3 cylinders. See *fig. 11*. The end of the '**X**' marked vane should be whitened for this operation.

The magneto rotates at crankshaft speed in a clockwise direction when viewing drive gear end. The rotor turns at half engine speed.

DISTRIBUTOR - BATTERY IGNITION

On engines equipped with Flywheel Alternator or direct mounted Generator, battery ignition is used in place of magneto ignition. The distributor is of the automatic advance type, and rotor turns at **one-half engine speed** in a counter-clockwise direction. *Fig. 15* illustrates an early style distributor which is mounted to the end of the generator. Newer engines with Flywheel Alternator or belt driven alternator have the distributor mounted to an adapter attached to the gear cover.

The **spark advance** for normal speeds is 23°, the same as for magneto ignition. **Engine must be running at 2000 R.P.M. or over when adjusting spark advance.**

ELECTRICAL WIRING CIRCUIT

Note: Beginning with engine serial No. 3979526 the standard wiring circuits for all **12 volt** electrical equipment is **negative ground polarity**, in place of the previously furnished positive ground. All **6 volt** systems remain positive ground.

The wiring diagram, *Fig. 12*, illustrates a **negative ground** circuit. If polarity of generator is for a positive ground circuit (engines built previous to serial No. 3979526, terminal connections at ammeter, ignition coil and battery are just reversed from those illustrated.

SOLID STATE IGNITION DISTRIBUTORS

Many Wisconsin engines are now being equipped with a solid state ignition distributor. Detailed troubleshooting and repair information can be found in the rear section of this manual. *For repair parts, see your VG4D Illustrated Parts Catalog.*

DISTRIBUTOR TIMING

Remove screen over the flywheel air intake opening. This will expose the timing marks on flywheel shroud, also the **vane** on flywheel, marked by an '**X**' and the letters '**DC**'. See *Fig. 13*. Next, remove the spark plug from No. 1 cylinder and turn engine over slowly by the starting crank, at the same time hold a finger over the spark plug hole to determine the compression stroke.

Upon reaching the compression stroke, continue turning crank until the leading edge of the **marked vane** on the flywheel is in line with the **centerline mark** on the flywheel shroud of the No. 1 cylinder. See *Fig. 13*. The No. 1 piston is on top dead center in this position.

Remove distributor cap. The **centerline** of the **distributor rotor** should be in line with the **center** of the **notch** in the distributor housing. No. 1 cylinder is ready to fire in the retarded timing position, when the distributor rotor is in this position, See *Fig. 14*. If distributor rotor is not in the above mentioned position, withdraw the entire distributor.

Remove distributor rotor and take off the dust cover to expose the breaker points. Mount rotor back on distributor shaft. Assemble distributor with the **distributor rotor** in line with the **notch** in the distributor housing, as shown in *Fig. 14*, and the **primary terminal** pointing toward the generator **circuit breaker**. See *Fig. 15*. Be sure that **advance arm lock screw**, *Fig. 14*, which is mounted to the **distributor clamp** is tight, as a manual spark advance is not used with these engines.




Fig. 13




Fig. 14

With the *advance arm clamp screw* loose, turn the distributor body slightly in a counter-clockwise rotation so that the breaker points are firmly closed. Then turn the distributor body in a *clockwise* rotation until the *breaker points* are just *beginning to open*, See Fig. 14. At this point a slight resistance can be felt as the breaker point cam strikes the breaker point arm. Tighten *advance arm clamp screw*. The No. 1 cylinder is now ready to fire in the retarded position, with the centerline of the *distributor rotor* in line with the center of the *notch* in the distributor body as shown in Fig. 14.

The breaker point gap should be .018 to .022 inches. This opening should be checked before the distributor body is set, otherwise any adjustment made to the breaker point opening will change the ignition advance. Replace distributor dust cover. If care is exercised in the above operations, the spark timing should be accurate enough for satisfactory operation, however, checking spark advance with a neon lamp, as described in 'Neon Lamp Timing' is recommended.

The four ignition cables from the distributor should be connected to the proper spark plugs. The cylinder shroud covers are marked for identification. The No.




Fig. 15

1 terminal tower on the distributor is in line with the notch in the distributor body. Terminal sequence is 1-3-4-2 in a counter-clockwise rotation. See Fig. 15.

NEON LAMP TIMING

The engine should be timed to the 23° advanced position at not less than 2000 R.P.M. Check timing with a neon lamp connected in series with No. 1 spark plug. Chalk or paint the end of the 'X' marked vane on the flywheel, white. Then with the engine operating at 2000 R.P.M. or over, allow the flash from the neon lamp to illuminate the whitened vane. At the time of the flash, the leading edge of the vane should line up with the *running spark advance timing hole* on the flywheel shroud, see Fig. 13. If it does not, the *advance arm clamp screw* should be loosened as shown in Fig. 14, and the distributor body turned slightly clockwise or counter-clockwise, as required, until the *white flywheel vane* matches up with the *advance timing hole*. Be sure *advance arm clamp* is then carefully tightened. If the engine is running below 2000 R.P.M. when timing, the automatic advance in the distributor will not be fully advanced and damages to the engine may result when the engine is operated at higher speeds. Mount flywheel screen if removed. For convenience, a 3/8" dia. hole was added to screen rim to check timing without removing screen.

DISTRIBUTOR AND GENERATOR MAINTENANCE

The distributor breaker point gap should be .018 to .022 inches. To readjust breaker point gap, turn engine over by means of the starting crank until the distributor breaker arm *rubbing block* is on a high point of the *cam*. Loosen the *stationary contact locknut* and screw *fixed contact*, in or out, until correct gap is obtained. Tighten locknut and recheck gap.

The generator and distributor should be periodically lubricated and inspected for external conditions which would affect their operation.

It is recommended that the generator oiler, located below the primary terminal of the distributor, be given

3 to 5 drops of medium engine oil every 50 hours.

Every 50 hours of operation, the oiler on the side of the distributor base should have 3 to 5 drops of medium engine oil added and the grease cup given one complete turn. Use a high melting point grease. Every 100 hours apply 3 to 5 drops of medium engine oil to the felt in the top of the cam sleeve. **Do not over-lubricate.**

CHARGING SYSTEM

Engines can be equipped with a 10 amp, 25 amp, or 30 amp flywheel alternator system or a 37 amp belt driven alternator. Instructions are located in rear of this manual.

FIRING ORDER

The firing order of the cylinder is **1-3-4-2**, and the magneto and battery type distributor rotate at one-half engine speed, as is the case with conventional 'in line' engines. The intervals between the firing of the cylinders is 180°. No. 1 cylinder is the one nearest to the flywheel in the left bank of cylinders, when viewed from the flywheel end of the engine. No. 3 cylinder is the other cylinder in this bank. No. 2 cylinder is the one nearest to the flywheel in the right bank of cylinders and No. 4 is the other cylinder in this bank. The cylinders are numbered from 1 to 4 on the air shroud near the spark plugs. See Fig. 1. The flywheel end of the engine is designated the **front**, and the power take-off end, the **rear** of the engine.

SPARK PLUGS, Fig. 16

Incorrect gap, fouled or worn spark plug electrodes, will have an adverse affect on engine operation. Remove spark plugs periodically, clean, regap or replace if necessary. Thread size is 18 mm.

Spark plug gap – 0.030 of an inch.

Replacement plugs must be of the correct heat range, like Champion No. D-16J, AC No. C86 commercial. Tighten spark plugs, 25 to 30 foot pounds torque.

RESTORING COMPRESSION

In a new engine or one which has been out of operation for some time, oil may have drained off the cylin-

ders so that compression will be weak, causing difficulty in starting. To remedy this condition, remove the sparkplugs and pour about a fluid ounce of crankcase oil through the spark plug hole into each cylinder. Turn engine over several times with the hand crank to distribute oil over the cylinder walls. Assemble spark plugs and compression should be satisfactory.

HIGH TEMPERATURE SAFETY SWITCH

As a safety precaution against overheating, engines can be equipped with a high temperature switch mounted to the cylinder head at the **No. 2** spark plug.

When cylinder head temperature becomes critically high, the safety switch will automatically stop the engine by shorting out the ignition system. A waiting period of about **15 minutes** will be required before the switch has cooled off sufficiently to re-start the engine. An overheated engine will score the cylinder walls, burn out connecting rod and crankshaft bearings, also warp pistons and valves. The cause of the overheating condition will have to be remedied before the engine is re-started. See **Engine Overheats** paragraph in **Troubles, Causes and Remedies** section.

KEEP ENGINE CLEAN - PREVENT OVERHEATING (Agricultural and Industrial Engines)

This engine is cooled by blasts of air which must be allowed to circulate all around the cylinders and cylinder heads to properly cool the engine and thereby keep it in good running condition. **If dust, dirt or chaff is allowed to collect in the cylinder shrouding or in the V between the cylinders**, it will retard the flow of air and cause the engine to overheat. Keep **flywheel screen** and **rotating screen** clean, so as not to restrict the intake of cooling air.

With reference to Fig. 17; follow the cleaning and maintenance instructions pointed out, to obtain trouble free and satisfactory engine performance.




Fig. 16




Fig. 17

1. Remove these covers frequently and clean out all dust and chaff. Be sure to replace covers.
2. Open these covers frequently and clean out all dust and chaff. Be sure to close covers.
3. Keep this space between cylinders free of dust and chaff.
4. Read instructions on this air cleaner regarding its care. This is important. The entire pre-cleaner and air cleaner should be removed from the engine at least once a year, and washed in a cleaning fluid to clean out dirt gathered in the back fire trap in the top part of the air cleaner.
5. Replace this oil filter cartridge every other oil change. If operating conditions are extremely dusty replace cartridge every oil change. Be sure that your replacement is a Wisconsin Micro-Fine filter.
6. Do not allow shrouding to become damaged or badly dented as this will retard air flow.

Never operate engine with air shrouding removed. This will retard air cooling.

Always keep all parts of the engine clean. This will prolong engine life, and give more satisfactory operation.

Every 4 to 8 hours, depending on dust conditions, check air cleaner and change oil. *See Page 10.*

Every 8 hours check crankcase oil level. Keep filled to **full** mark on oil gauge saber, but no more. *See Fig. 3.*

Every 50 hours, drain crankcase and refill with fresh oil. *See Lubrication, Pages 6 and 7.*

SUGGESTION FOR CONTINUOUS HOT WEATHER OPERATION

The intake system of a gasoline engine is designed so that the fuel may be vaporized and mixed with the correct amount of air for proper combustion in the cylinders. To vaporize the fuel, a certain amount of heat must be supplied to the intake manifold. The temperature of the air to the carburetor varies considerably between summer and winter weather, so that in designing the intake manifold a happy medium must be chosen for the amount of heat supplied. This heat is usually taken from the exhaust manifold through a connection called a hot spot, between the two manifolds. The size of this hot spot is very important. If it is too small, insufficient heat will be supplied to the inlet manifold and carburetor in cold weather, and poor vaporization of fuel and irregular operation of the engine will result, with loss of power. If the hot spot is too large, the inlet manifold and carburetor will be too hot in summer weather and this will result in heating the engine unnecessarily, and there will also be loss in power. There might also result, some vapor lock, due to overheating the fuel in the carburetor, or in the fuel feed lines to the carburetor. Vapor lock is fuel in a gaseous state, in the fuel lines or in the smaller passages in the carb-

uretor, preventing the flow of fuel, thus stopping the engine.

If an engine is stopped by vapor lock, there will be considerable difficulty in starting the engine again, until it has cooled off sufficiently to overcome the vapor lock, and thus allow the fuel to flow normally.

Vapor lock, or a hot inlet manifold and carburetor, which will vaporize the fuel too rapidly, resulting in an over rich mixture, are the main reasons for hard starting of hot engines. This condition is more apt to occur with four cylinder, rather than with one or two cylinder engines.

The following suggestions will help considerably to overcome these hard starting problems:

If the engine has been running hard and is hot, do not stop it abruptly from full load, but remove the load and allow engine to run idle at 1000 to 1200 R.P.M. for three to five minutes, depending on how hot the engine has been. This will reduce the internal temperature of the engine much faster than stopping the engine, and of course the external temperature, including the manifold and carburetor, will also reduce faster.




Fig. 18

In extreme cases, four-cylinder engines which operate mainly in hot weather, can be benefitted by reducing the width of the hot spot between the inlet and exhaust manifolds, to about one half or less, by sawing in from each side with a hack saw. The width of the hack saw cut (about 1/32 inch) is sufficient to reduce the heat flow and reduce inlet manifold and carburetor temperatures, and improve hot starting conditions. *See Fig. 18.*

TROUBLES CAUSES AND REMEDIES

Three prime requisites are essential to starting and maintaining satisfactory operation of gasoline engines. They are:

1. **A proper fuel mixture** in the cylinder.

2. **Good compression** in the cylinder.

3. **Good spark, properly timed**, to ignite the mixture.

If all three of these conditions do not exist, the engine cannot be started. There are other factors which will contribute to hard starting; such as, too heavy a load for the engine to turn over at a low starting speed, a long exhaust pipe with high back pressure, etc. These conditions may affect the starting, but do not necessarily mean that the engine is improperly adjusted.

As a guide to locating any difficulties which might arise, the following causes are listed under the three headings: **Fuel Mixture, Compression, and Ignition.**

In each case, the causes of trouble are given in the order in which they are most apt to occur. In many cases the remedy is apparent, and in such cases no further remedies are suggested.

STARTING DIFFICULTIES

FUEL MIXTURE

No fuel in tank or fuel shut-off valve closed.

Fuel pump diaphragm worn out, so pump does not supply carburetor with fuel.

Carburetor not choked sufficiently, especially if engine is cold. *See 'Choke', Page 8.*

Water, dirt; or gum in gasoline interfering with free flow of fuel to carburetor.

Poor grade or stale gasoline that will not vaporize sufficiently to form the proper fuel mixture.

Carburetor flooded, caused by too much choking, especially if engine is hot. *See 'Choke', Page 8.*

Dirt or gum holding float needle valve in carburetor open. This condition would be indicated if fuel continues to drip from carburetor with engine standing idle. Often tapping the float chamber of the carburetor very lightly with the wood handle of a screwdriver or similar instrument will remedy this trouble. Do not strike carburetor with any metal tools, it may cause serious damage. Also if the mixture in the cylinder, due to flooding, is too rich, starting may be accomplished by continued cranking, with the carburetor choke open.

If, due to flooding, too much fuel should have entered the cylinder in attempting to start the engine, the mixture will most likely be too rich to burn. In that case the spark plugs should be removed from the cylinders and the engine then turned over several times with the starting crank, so the rich mixture will be blown out through the spark plug holes. The choke on the carburetor should of course be left open during this procedure. The plugs should then be replaced and starting tried again.

To test for clogged fuel line, loosen fuel line nut at carburetor slightly. If line is open, fuel should drip out at loosened nut.

COMPRESSION

Compression check with a commercial compression test gauge can show whether or not an engine has faulty compression. TTP does not consider it practical to publish a PSI compression figure because of the variables involved: engine condition, method of testing, and RPM of test. Our recommendation is that whatever gauge test is performed, a 10% variance between cylinders would indicate leaking rings, leaking valves or any of the following:

Cylinder dry due to engine having been out of use for some time. *See 'Restoring Compression', Page 15.*

Loose spark plugs or broken spark plug. In this case a hissing noise will be heard when cranking engine, due to escaping gas mixture on compression stroke.

Damaged cylinder head gasket or loose cylinder head. This will likewise cause hissing noise on compression stroke.

Valve stuck open due to carbon or gum on valve stem. To clean valve stems, *see 'Valves', Page 22.*

Valve tappets adjusted with insufficient clearance under valve stems. *See 'Valve Tappet Adjustment', Page 24.*

Piston rings stuck in piston due to carbon accumulation. If rings are stuck very tight, this will necessitate removing piston and connecting rod assembly and cleaning parts. *See 'Piston and Connecting Rod' Page 21.*

Scored cylinders. This will require reboring of the cylinders and fitting with new pistons and rings. If scored too severely, an entirely new cylinder block may be necessary.

IGNITION

See 'Magneto Ignition Spark' Page 11 or 'Distributor-Battery Ignition', Page 13. No spark may also be attributed to the following:

Ignition cable disconnected from magneto or spark plugs.

Broken ignition cables, causing short circuits.

Ignition cables wet or soaked.

Spark plug insulators broken.

Spark plugs wet or dirty.

Spark plug point gap wrong. *See Page 15.*

Condensation on spark plug electrodes.

Magneto or Distributor breaker points pitted or fused.

Magneto or Distributor breaker arm sticking.

Magneto or Distributor condenser leaking or grounded.

Spark timing wrong. *See 'Magneto Timing', Page 12, or 'Distributor-Battery Ignition', Page 13.*

ENGINE MISSES

Spark plug gap incorrect. *See Page 15.*

Worn and leaking ignition cables.

Weak spark. *See 'Magneto Ignition Spark', Page 11, or 'Distributor-Battery Ignition', Page 13.*

Loose connections at ignition cable.

Magneto or Distributor breaker points pitted or worn.

Water in gasoline.

Poor compression. See 'Compression', Page 17.

ENGINE SURGES OR GALLOPS

Carburetor flooding.

Governor spring hooked into wrong hole in lever. See 'Governor Adjustment', Page 24. Governor rod incorrectly adjusted. See 'Governor Adjustment', Page 24.

ENGINE STOPS

Fuel tank empty.

Water, dirt or gum in gasoline.

Gasoline vaporized in fuel lines due to excessive heat around engine (Vapor Lock). See 'Stopping Engine', Page 9.

Vapor lock in fuel lines or carburetor due to using winter gas (too volatile) in hot weather.

Air vent hole in fuel tank cap plugged. Engine scored or stuck due to lack of oil.

Ignition troubles. See 'Ignition', Page 17.

ENGINE OVERHEATS

Crankcase oil supply low. Replenish immediately.

Ignition spark timed wrong. See 'Magneto Timing', Page 12, or 'Distributor-Battery Ignition', Page 13.

Low grade of gasoline.

Engine overloaded.

Restricted cooling air circulation.

Part of air shroud removed from engine.

Dirt between cooling fins on cylinder or head.

Engine operated in confined space where cooling air is continually recirculated, consequently becoming too hot.

Carbon in engine.

Dirty or incorrect grade of crankcase oil.

Restricted exhaust.

Engine operated while detonating due to low octane gasoline or heavy load at low speed.

ENGINE KNOCKS

Poor grade of gasoline or of low octane rating. See 'Fuel', Page 8.

Engine operating under heavy load at low speed.

Carbon or lead deposits in cylinder head.

Spark advanced too far. See 'Magneto Timing', Page 12, or 'Distributor-Battery Ignition', Page 13.

Loose or burnt out connecting rod bearing.

Engine overheated due to causes under previous heading.

Worn or loose piston pin.

ENGINE BACKFIRES THROUGH CARBURETOR

Water or dirt in gasoline.

Engine cold.

Poor grade of gasoline.

Sticky inlet valves. See 'Valves', Page 22.

Overheated valves.

Spark plugs too hot. See 'Spark Plug', Page 15.

Hot carbon particles in engine.

DISASSEMBLY AND REASSEMBLY OF VG4D ENGINE

Engine repairs should be made only by a mechanic who has had experience in such work. When disassembling the engine it is advisable to have several boxes available so that parts belonging to certain groups can be kept together, such as, for instance, the cylinder head screws, etc. Capscrews of various lengths are used in the engine, therefore great care must be exercised in reassembly so the right screw will be used in the various places, otherwise damage may result.

Tighten the cap screws and nuts of the manifolds, cylinder heads, gear cover, oil pan, connecting rods, cylinder blocks, main bearing plate and the spark plugs to the specified torque readings indicated in the following paragraphs of reassembly.

While the engine is partly or fully dismantled, all of the parts should be thoroughly cleaned. Remove all accumulated dirt between the fins.

If it is desired to disassemble the engine, the following order should be substantially adhered to. As disassembly progresses, the order may be altered somewhat if desired, as will be self-evident to the mechanic. Reassembly of the engine should be made in the reverse order.

TESTING REBUILT ENGINE

An engine that has been completely overhauled, such as having the cylinders rebored and fitted with new pistons, rings and valves, should go through a thorough "run-in" period, before any amount of load is applied to the engine.

The engine should be started and allowed to run for about one-half hour, at about 1200 to 1400 R.P.M. without load. The R.P.M. should then be increased to engine operating speed, still without load, for an additional three and one-half to four hours.

The proper "running-in" of the engine will help to establish polished bearing surfaces and proper clearances between the various operating parts and thus add years of trouble free service to the life of your engine.

ACCESSORIES

The air cleaner, oil filter, magneto, and if an electric starter and generator are used, these should be removed first.

Remove clutch or clutch reduction unit if engine is equipped with either of these accessories.

SHEET METAL HOUSE

On power units, engines which are enclosed in a sheet metal house, remove the muffler and canopy first. Disconnect air cleaner, choke, governor control and instrument wires at the front house panel. The front panel can be removed as part of the flywheel shroud, as explained in the following paragraphs of disassembly.

FLYWHEEL

After the flywheel screen has been removed, drive out the starting crank pin in the crankshaft and remove the flywheel nut and washer.




Fig. 19

The flywheel is mounted to a taper on the crankshaft. Take a firm hold on the flywheel fins, pull outward and at the same time strike the end of the crankshaft with a babbitt hammer, see Fig. 19. The flywheel will slide off the taper of the crankshaft. Do not use a hard hammer as it may ruin the crankshaft and bearings. When reassembling the flywheel, be sure the Woodruff key is in position on the shaft and that the keyway in the flywheel is lined up accurately with the key. **Tighten flywheel mounting nut to 95-110 foot pounds torque.**

AIR SHROUDING

To disassemble air shrouding, refer to Fig. 20. First remove cylinder head covers and the screws mounting the flywheel shroud to the lower cylinder shrouds and cylinder heat deflectors; then remove the screws holding the flywheel shroud to gear cover.




Fig. 20




Fig. 21

On power units, remove the front end panel as shown in Fig. 21, together with flywheel shroud. Disassemble rear end panel, as shown in Fig. 22, complete with fuel tank. Balance of shrouding can now be readily removed.

FUEL TANK

If a side mount gasoline tank is used, this should be removed next. See Fig. 23.

CARBURETOR AND MANIFOLDS

The carburetor and manifold can be removed as a complete unit as shown in Fig. 24.




Fig. 22




Fig. 23




Fig. 24

In reassembly, tighten the nuts for mounting the manifolds to **32-35 foot pounds torque**. Tightening beyond specification may cause the flanges to break.

CYLINDER HEAD

The cylinder head must be removed if it is necessary to regrind valves, or to do work on the piston rings or connecting rod. All of the cylinder head screws are plainly in view and can be easily removed. Screws of different lengths are used but these can be properly reassembled according to the various lengths of cylinder head bosses.

Before reassembling the cylinder head, all carbon and lead deposits should be removed. It is recommended that a new cylinder head gasket be used in reassembly, as the old gasket will be compressed and hard so that it may not seal properly. Use a mixture of graphite and oil on the cylinder head screws, the prevent them from rusting tight against the cylinder block. Tighten cylinder head screws, **28 - 32 foot pounds torque**. After complete assembly and engine is run-in, re-torque head screws.

GEAR COVER

Disconnect the governor linkage and remove the governor assembly. Remove gear cover screws and drive out the two dowel pins as shown in *Fig. 25*. The gear cover can then be taken off, exposing the timing gears as shown in *Fig. 26*. In reassembly, tighten gear cover capscrews, **16 - 18 foot pounds torque**.




Fig. 25

CAMSHAFT GEAR

Remove the three capscrews and lockwashers which hold the gear to the end of the camshaft. Note that the mounting holes in the camshaft gear are staggered in such a manner that the gear can be assembled to the shaft only one way which will automatically time the gear to the shaft. Pry the gear off the camshaft using a screwdriver or similar wedge tool.

IDLER GEAR AND SHAFT

Remove the Allen head set screw on the magneto




Fig. 26




Fig. 27

side of the crankcase which locks the idler shaft in position. With the use of a gear puller, the idler shaft and idler gear assembly can be removed from the crankcase. See Fig. 27. *In reassembly*; allow .003" to .004" clearance between idler gear and stud collar.

OIL PAN (Fig. 28)

The engine can now be inverted to that the supports and oil pan can be removed. *In reassembly*; mount deep end of oil pan toward oil pump. Tighten mounting screws, **8-11 foot pounds torque**.

OIL PUMP (Fig. 29)

Remove locknut and driver gear from shaft. If gear is too tight to remove by hand, use a puller; **hammering** on end of shaft to loosen gear will **damage pump**.

Take out slotted pipe plug from bottom of crankcase. By means of a 5/32 inch Allen wrench, remove lock-screw from pipe plug hole. Withdraw oil pump from inside crankcase. If pump fits too tight to remove by hand, tap front of pump housing (not shaft), with hammer and brass rod.




Fig. 28




Fig. 29

PISTONS and CONNECTING RODS (Figs. 30, 31, 34)

By means of a 9/16" socket wrench, loosen and remove the hex locknuts from connecting rod bolts. Then, by tapping the ends of the bolts lightly, the connecting rod cap will break free from the bolts.

Scrape off all carbon deposits that might interfere with removal of pistons from upper end of cylinder. Turn crankshaft until piston is at top, then push connecting rod and piston assembly upward and out thru top of cylinder. Be careful not to mar the crank pin by allowing the rod bolts to strike or scrape across it. Place caps on rods immediately so that they will not be mismatched in reassembly. Be sure that shims (used in babbitt bearing rods), are in place before cap is put on.

NOTE: This model engine was originally furnished with **babbitt cast** connecting rod bearings. **Shell bearing** rods are now being used for current production engines, and are interchangeable with babbitt bearing rods for service replacement. Care should be taken in **reassembly** to mount bearings properly. The cap should be assembled to the rod so that the **locating**




Fig. 30




Fig. 31

lug of both bearing halves are on the same side as illustrated in *Fig. 30*. Refer to chart, *Fig. 34*, for clearance between bearing and crank pin.

The piston skirt is *cam-ground* to an elliptical contour. Clearance between the piston and cylinder must be measured at the center of the thrust face at the bottom of the piston skirt. Refer to Chart, *Fig. 34*, for proper clearance. The thrust faces on the piston skirt are 90° from the axis of the piston pin hole, with the wide section of the piston skirt toward the maximum thrust side, or opposite the crankshaft rotation. See *Engine Sectional, Fig. 2*. The VG4D was originally designed with *split-skirt* pistons which were mounted with the split toward the direction of crankshaft rotation (clockwise facing flywheel end).

In reassembly; be sure piston and connecting rod assemblies are put back into the same bore from which they were removed. Use a suitable ring compressor and stagger the piston ring gaps 90° apart around the




Fig. 32




Fig. 33

piston. Oil the pistons, rings, wrist pins, rod bearings and cylinder walls before assembly.

CAUTION: Identical numbers are stamped on the side of the rod with its corresponding cap. These numbers must be on the same side of the connecting rod when mounted in engine. Be sure that *oil hole* in connecting rod cap is facing toward the oil spray nozzle, as illustrated in *Fig. 31*. **Install new nuts** on connecting rod bolts and **torque 28-32 foot pounds**.

PISTON RINGS (Fig's. 32, 33, 34)

If a ring expander tool is not available, install rings by placing the open end of ring on piston first, as shown in *Fig. 32*. Spread ring only far enough to slip over piston and into correct groove, being careful not to distort ring. Install bottom ring first and work toward the head of the piston, installing top ring last.

Each piston has two compression rings, a scraper ring with expander, and an oil control ring. The outer diameter of the top compression ring is *chrome plated*. Mount scraper ring with scraper edge down, otherwise oil pumping and excessive oil consumption will result. See *Fig. 33* for the correct ring placement.

CYLINDER BLOCKS

Clean all dirt and foreign deposits from between the cylinder fins and manifold ports.

PISTON TO CYLINDER AT PISTON SKIRT	SPLIT-SKIRT	CAM-GROUND
		.004 to .005"
PISTON RING GAP		.010 to .020"
PISTON RING SIDE CLEARANCE IN GROOVES	TOP RING	.0015 to .0035"
	2nd, 3rd RING	.0015 to .0035"
	OIL RING	.002 to .004"
PISTON PIN TO CONNECTING ROD BUSHING		.0005 to .0011"
PISTON PIN TO PISTON		.0000 to .0008" tight
CONNECTING ROD TO CRANK PIN - SIDE CLEARANCE		.009 to .016"
CONNECTING ROD SHELL BEARING TO CRANK PIN DIA. (VERTICAL)		.0013 to .0035"
CONNECTING ROD BABBITT BEARING TO CRANK PIN		.0015 to .0028"




Fig. 34, PISTON, RING AND ROD CLEARANCES CHART




Fig. 35

The cylinder blocks do not have to be removed unless the cylinder bore is scored, out-of-round, or worn over-size more than 0.005 inch. In this event, the block will have to be removed, rebored and fitted with over-

size pistons and rings. *In reassembly*, use new gaskets and tighten cylinder block mounting nuts to **56-62 foot pounds torque**.

VALVES and SEAT INSERTS (Fig. 35)

Remove tappet inspection cover and compress valve springs with a standard automotive valve lifter. Wedge a rag into the opening at the bottom of valve chamber so the retaining locks do not fall into crankcase. Remove retaining locks, seats, springs, valves and clean these, as well as the ports and guides, of all carbon and gum deposits. Tag each valve so that they can be put back into the same guides they were removed from. Replace valves that are burned or pitted.

The exhaust valves are furnished with **positive type rotators**. The valve rotates slightly each time it opens, and thereby prevents the build up of foreign deposits on the valve face and stem. Clean and inspect operation of rotator - replace if necessary.

The inlet and exhaust valve **seat inserts** can be removed, when replacement becomes necessary, by means of Wisconsin Motor **DF-68-A** insert puller.

Before grinding valves, inspect valve guides for possible replacement. Refer to *Valve Guide* paragraph. The valve face is ground at 45° to the vertical center line of the valve stem and the valve seat insert should also be ground at a 45° angle. *After grinding*, lap valves in place until a uniform ring will show entirely around the face of the valve. Clean valves and wash block thoroughly with a hot solution of soap and water. Wipe cylinder walls with clean lint free rags and light engine oil.

Valve guides in the cylinder block are easily replaceable by use of Wisconsin **DF-72 driver tool**. The valve stem has a clearance of .003 to .005" in the guide. When the clearance becomes .007", the guides should be driven out and replaced.

CRANKSHAFT (Fig. 36)

Remove main bearing plate at take-off end. The crankshaft can then be taken out from that end of crankcase. *In reassembly*, use same thickness of gaskets and shims to establish the correct end play for the tapered main roller bearings.




Fig. 36

End play should be .002 to .005 inch when engine is cold. There is practically no wear in this type main bearing so end play readjustment is seldom necessary once it is properly made.

When reassembling crankshaft, the timing marks on the crankshaft gear and the camshaft gear must be matched, *see Fig. 26*, otherwise engine will not operate properly, or if timing is off considerably, engine will not run at all.

Mount main bearing plate in the correct position in reassembly. The word 'TOP' is cast on the outside of the plate, and should be mounted in this position. Mounting the main bearing plate upside down would prevent the main bearing from being properly lubricated. Tighten main bearing plate capscrews, 25 to 30 foot pounds torque.

CAMSHAFT

The camshaft can be withdrawn from the flywheel end of the engine. *See Fig. 37*. When replacing, be sure the spring and plunger are in place in the end of the camshaft, as these hold the camshaft in position endwise. These parts are shown in the sectional view of the engine, *Fig. 2*.




Fig. 37




Fig. 38

VALVE TAPPETS

The valve tappets should be pulled out before the camshaft is removed. In reassembly, the tappets can be inserted in proper position in the crankcase after the camshaft is reassembled. *See Fig. 37*.

After the cylinders have been reassembled to the crankcase, the inlet and exhaust valve tappets should be adjusted as shown in *Fig. 38*. Adjust tappet clearance, when cold, to a clearance of:

Inlet - 0.008 inch
Exhaust - 0.016 inch

GOVERNOR - ADJUSTMENT

The centrifugal flyball governor rotates on a stationary pin driven into the upper part of the timing gear cover, and the governor is driven off the camshaft gear at $1-1/8$ times crankshaft speed.

The flyweights are hinged to lugs on a drive hub behind the gear. Hardened pins on the flyweights bear against the flanged sliding sleeve, moving it back and forth as the flyweights move in or out. The motion of the sleeve is transmitted through a ball thrust bearing to the governor lever, which in turn is connected to the carburetor throttle lever. A spring connected to the governor lever tends to hold the governor flyweights to their inner position, also to hold the carburetor throttle open. As the engine speed increases, the centrifugal force in the flyweights acts against the spring and closes the throttle to a point where the engine speed will be maintained practically constant under varying load conditions. This speed can be varied to suit conditions by adjusting the governor spring tension to suit.

The control rod between the governor and carburetor must be adjusted to the proper length otherwise the governor action will be faulty. With the engine at rest the governor spring will hold the flyweights in, and the control rod must be of such length as to hold the carburetor throttle wide open at that point. With the *control rod* disconnected from the *governor lever*, push the rod toward the carburetor as far as it will go. This will put the *carburetor throttle lever* in a wide open position. The governor lever should then be moved as far as possible in the same direction. Holding both parts in the above position, the rod should be screwed in or out of the *swivel block* on the carburetor, until the bent end of the rod will register with *hole* in lever, then screw rod in one more turn. The extra turn will shorten the linkage slightly and will enable the carburetor throttle lever to bounce back from the stop pin rather than jam against the pin, when a load is suddenly applied to an idling engine. This will eliminate excessive wear on the threads in the carburetor throttle swivel block.

The construction of the governor can be best seen from the sectional drawing of the engine, *Fig. 2*.

The governor lever is furnished with 12 holes for attaching the governor spring as shown in *Fig. 39*. It


FULL LOAD R.P.M.	NO LOAD R.P.M.	HOLE NO.	GOVERNOR LEVER	HOLE NO.
1400	1550	4		12
1500	1650	5		11
1600	1725	5		10
1700	1850	6		9
1800	1950	7		8
1900	2050	8		7
2000	2125	8		6
2100	2250	9		5
2200	2350	10		4
2300	2425	10		3
2400	2550	11		2
			1	

Fig. 39

is very important that the spring is hooked into the proper hole to suit the speed at which the engine is operated. The Governor Lever Chart, *Fig. 39*, shows the *full load* and *no load* speeds of the engine and the hole corresponding thereto. The full load speed will be from 150 to 125 revolutions less than the no load speed. As an example, if the engine is to be operated at 2000 revolutions per minute under load, the spring should be hooked into the 8th hole in the governor lever and the spring tension adjusted, by means of the adjusting screw connected to the spring, to run 2125 revolutions per minute, without load. The speed at full load will then be approximately 2000 revolutions per minute. A tachometer or revolution counter should be used against the crankshaft while adjusting the governor spring tension to give the proper engine speed.

CLUTCH AND REDUCTION UNITS

CLUTCH POWER TAKE-OFF UNIT

The clutch furnished with this model of engine is of the dry disc type. No oil should be put into the clutch housing. There are three points on these clutches requiring lubrication and these are filled with grease at the factory, see *Fig. 40*. *Grease gun fittings* are furnished for periodic lubrication. The housing bearing should receive additional grease every fifty hours of operation. The clutch throwout bearing should be greased every day before starting. Use Mobil Gargoyle grease BRB No. 3, or Sinclair AF-1 grease, or equal.

CLUTCH ADJUSTMENT

If the clutch begins to slip, it should be readjusted, otherwise it would become overheated and damaged. First release clutch operating lever and remove clutch inspection plate. For the *Rockford clutch*, turn clutch over until *adjusting ring lock* is up. Release lock with a screw driver or similar tool as shown in *Fig. 41*. The *adjusting ring* should then be turned in




Fig. 40




Fig. 41

a clockwise direction one notch at a time until a very firm pressure is required to engage the clutch by the operating lever. Be sure to re-engage the adjusting ring lock into a notch in the ring. Replace inspection cover.

For the *Twin Disc* clutch, pull *adjusting lockpin* out and insert a piece of 1/16" diameter wire into the hole on the side of the lockpin to keep pin in outer




Fig. 42

position. See Fig. 42. Turn the *adjusting yoke* in a clockwise direction as shown, or wedge a screw driver into the adjusting yoke and against the side of the inspection hole opening, to keep yoke from turning, and then turn the take-off shaft counterclockwise. Tighten yoke enough so that the *operating lever* requires a distinct pressure to engage. Remove wire from lockpin and turn adjusting yoke slightly, to allow lockpin to snap into hole in floating plate.

CLUTCH REDUCTION UNITS

Clutch reduction units are furnished with several different ratios, some with spur gears, for counter-enginewise rotation, others with internal gears, for enginewise rotation. The clutch is of the dry disc type and no oil should be put into the clutch housing. Apply a small amount of lubricant to clutch throwout collar once a day before starting. Also oil clutch




Fig. 43

shifter shaft through oil fittings on each side of housing. See Fig. 43. The clutch shaft pilot bearing and outer bearing are self lubricated with oil in gear case.

The reduction unit is operated in oil and the gear case oil level must be maintained to the oil level plug, see Fig. 43. In *Twin Disc* units, high grade transmission oil S.A.E. No. 90 to No. 110 Viscosity must be used. For *Rockford* units, use No. 30 S.A.E. crankcase oil. Change oil every 2000 hours of service, while unit is warm.

If clutch slips, heats, or operating lever jumps out, the clutch must be adjusted. Release clutch operating lever and remove hand hole plate. The *clutch* in the clutch reduction units is the same as is used in the clutch power take-off units. Refer to "Clutch Adjustment" paragraph for adjustment of the clutch in the *Twin Disc* and *Rockford* clutch reduction units. A new clutch generally requires several adjustments until the friction surfaces are worn in.

INSTRUCTIONS FOR PROTECTING ENGINE FOR A SHORT PERIOD BETWEEN OPERATING INTERVALS

When the work interval is completed, the following instructions should be carried out very carefully to protect the engine.

The outside of the engine, including the cooling fins on the cylinders and heads, should be thoroughly cleaned of all dirt and other deposits.

The air cleaner at the carburetor intake should be thoroughly cleaned of all oil and accumulated dust, and the sediment removed from the oil cup at the bottom of the cleaner.

To protect the cylinders, pistons, rings and valves and keep them from rusting and sticking, a half and half mixture of kerosene and good gas engine oil, (the same kind of oil as used in the crankcase of the engine), should be injected into the pipe tap opening on the intake manifold while the engine is warm and running at moderate speed. About a quarter of a pint is necessary on a four cylinder engine, or enough so that a heavy bluish smoke will appear at the exhaust. The ignition switch should then be shut off and the engine stopped. This fogging operation will give a coating of oil on the above mentioned parts, protecting them from the atmosphere.

On engines where the pipe tap opening on the intake manifold is inaccessible, the rust preventative may be injected into the air intake on the carburetor while the engine is running, so the mixture will be drawn into the engine. The air cleaner connection will of course have to be disconnected from the carburetor to do this.

All old used oil should be drained from the crankcase while the engine is warm, as the oil will then flow much more freely than when cold.

Drain fuel system, including gasoline lines, carburetor, fuel pump and tank of all gasoline to prevent

lead and gum sediment interfering with future operation.

The air cleaner or carburetor intake, as well as the exhaust manifold and breather openings, should be taped or otherwise sealed off, for the duration of the storage period.

All exposed unpainted metal parts should be coated with grease or heavy oil.

Before starting the engine again, the crankcase drain plug should again be removed, so that any condensation, which may have collected, may be drained before new crankcase oil is added.

A good plan, and one that is recommended, is to remove the crankcase bottom cover or oil base before starting the engine, and scrubbing off all sediment which may have collected there.

When replacing the bottom cover, a new gasket should be used.

Be sure to fill the crankcase with a good quality of crankcase oil to the high level point, before starting the engine. Do not use any oil heavier than SAE No. 30. Also be sure to put oil to the proper level in the air cleaner. (See Lubrication, Page 7, and Air Cleaner, Page 10.)

It is also recommended to use new spark plugs at the beginning of the operating interval, especially if the engine has given considerable service.

Refuel engine and follow the starting instructions as shown on preceding pages of this manual.

It is highly recommended that machines be stored inside a building. If this is not possible, the engine should be protected from the weather by a proper covering.

ACCESSORIES & OPTIONS

Operation and Service Instructions

- **FUEL PUMP**
- **FLYWHEEL ALTERNATOR**
- **CARBURETOR**
- **MAGNETO**
- **SOLID STATE IGNITION DISTRIBUTORS**

Major repairs of Alternator (automotive type), Ignition Distributor, Magneto and Starting Motor may require special tools and testing equipment. It is suggested that these repairs be done at either an Authorized Distributor or the Accessory Manufacturer's dealer.

FUEL PUMP SERVICE INSTRUCTIONS


WISCONSIN FUEL PUMPS, No. LP-38E, LP-38H and LP-38F (Cold Weather: -65°F)

For all 4 cylinder engine models

The fuel pump, like all other parts of the engine, is subject to wear and you will find that any time after 500 hours of use, its efficiency will gradually decrease. This is indicated by the engines faltering at high speeds or when heavy loads are suddenly applied. The pump can easily be restored to its normal efficiency by the installation of a repair kit. Wisconsin LQ-46 (for LP-38E), LQ-47 (for LP-38H) or LQ-46A (LP-38F, cold weather, - 65°).

1. Disconnect fuel lines from pump and remove fuel strainer if mounted to pump. Remove fuel pump from adapter housing by taking out the two mounting screws.
2. File a groove across a point at the union of castings (15 and 16). This is a positive location of the fuel INLET and OUTLET positions when reassembling. Remove six head to flange screws (3) and remove fuel head. Take off screw (2), remove cover (7) and discard cover gasket (4).
3. Turn fuel head (16) over and remove both valve assemblies (5), and gaskets (6). Note position of valves.
4. Clean head thoroughly with kerosene or diesel fuel and a fine brush.
5. Place fuel head (16) with diaphragm surface up. Assemble new valve gaskets (6) and mount valve assemblies (5) in positions shown on illustration. Press valves in evenly without distortion and stake in place.
6. Mount new cover gasket (4), cover (7) and washer (8). Securely tighten in place with cover screw (2).
7. Set fuel head assembly aside and proceed to rebuild lower diaphragm section.
8. Insert the end of a small screw driver into the coils of rocker arm spring (12) and remove.
9. Hold mounting bracket (15) in the left hand, with the rocker arm toward your body and the thumb nail on the end of link (10). With the heel of right hand on diaphragm (1), compress the diaphragm spring (11), and at the same time pull toward your body. Unhook link (10) from end of diaphragm and remove.
10. Remove rocker arm pin (13). Note that pin is larger on one end. Drive pin out by means of a punch from small end.
11. Clean mounting bracket (15) with kerosene or diesel fuel.
12. Assemble new link (10), bushing (9) and pin (13) to bracket (15) along with rocker arm (14). Stake rocker arm pin (10) in bracket to keep it in place.
13. Place new diaphragm spring (11) into bracket (15). Repeat in reverse order paragraph 9, using a new diaphragm (1). Assemble new rocker arm spring (12).
14. Mount this assembly to adapter on engine using new flange gasket (17).
15. Crank the engine over to a position where the diaphragm (1) is laying flat on the mounting bracket (15). Place the fuel head assembly back in position so the locating grooves of Step 2 are in line, and start the six head screws approximately three turns. Again crank the engine over to where the diaphragm (1) is pulled down into mounting bracket (15) to its lowest position. Securely tighten the six head screws (3).
16. Mount fuel strainer to fuel inlet and connect fuel lines.

NOTE: The LQ-46, LQ-47 or LQ-46-A Repair Kit and the parts included there-in, which are identified by an asterisk (*), are the only parts of the fuel pump available for service.



Ref. No.	Description	No. Req.
* 1	DIAPHRAGM	1
2	COVER SCREW	1
3	SCREW, head to bracket mounting	6
* 4	GASKET, cover (pulsator in LQ-47)	1
* 5	VALVE ASSEMBLY	2
* 6	GASKET for valve	2
7	COVER	1
8	WASHER for cover screw	1
* 9	BUSHING for rocker arm	1
* 10	LINK for rocker arm	1
* 11	SPRING for diaphragm	1
* 12	SPRING for rocker arm	1
* 13	PIN for rocker arm	1
14	ROCKER ARM	1
15	MOUNTING BRACKET	1
16	FUEL HEAD	1
* 17	GASKET for mounting flange	1

Flywheel Alternator

ELECTRICAL EQUIPMENT

The **12 volt** Battery Ignition Distributor with Coil and Starting Motor are standard equipment. Options include: 10 amp, 25 amp, or 30 amp Flywheel Alternator, 37 amp Belt Driven Alternator, Instrument Panel, High-Temperature Safety Switch and Solenoid Starting. **Battery is not normally furnished with the engine.**

FLYWHEEL ALTERNATOR, Fig. 44

This flywheel alternator is of the permanent magnet type and has **no brushes, commutator, belts or adjustments**. A series of coils (stator) is mounted to the engine gear cover, and the magnetic flux is provided by a permanent magnet in the flywheel which rotates around these stationary coils. Only four components make up this light weight space saving system; a **flywheel** with magnetic rotor, **stator**, **rectifier** module and **regulator** module. The 30 amp flywheel alternator system uses a combination rectifier/regulator module.

IMPORTANT

This is a **Negative Ground** system. Charging components will be damaged if grounded wrong in connecting or jumping batteries.

Caution: Handle battery carefully to prevent acid burns. Avoid sparks near battery - gas given off by battery is explosive.

Since the physical appearance of both 10 amp and 25 amp **Flywheel Alternator** systems are very similar, they can be distinguished from each other by the ammeter calibrations; **0 to 15 amps** for the 10 amp circuit and **0 to 30 amps** for the 25 amp circuit, or by the wire from ammeter to stator-regulator connector; **16 gage red wire** for 10 amp, **14 gage green wire** for 25 amp circuit.





Fig. 44

PRECAUTIONS to be exercised in the use of Flywheel Alternator:

1. **Do not** reverse battery connections. Negative battery terminal must be grounded. Reverse polarity will damage rectifier.
2. Connect booster batteries - positive to positive and negative to negative.
3. **Do not** ground any wires from stator or modules which terminate at connectors, or from field terminal of belt driven alternator.
4. **Do not** operate engine with battery disconnected, or disconnect the alternator output lead while the alternator is operating, as damping effect of the battery will be lost. The voltage will rise to an extreme value and permanent damage to the regulator may occur.
5. **Do not** remove alternator from installation without first disconnecting the grounded battery cable.
6. Disconnect ground battery lead if a battery charger is used.

Fig. 45, **WIRING DIAGRAM**
ELECTRICAL SYSTEM
WITH
10 AMP or 25 AMP
FLYWHEEL ALTERNATOR



WIRING CIRCUIT, Fig. 44, Fig. 45

The *fool-proof* type connectors used prevent incorrect wiring from the stator to the rectifier and regulator modules. To disconnect plugs, squeeze outer ends of receptacle and pull apart.

The rectifier is insulated from ground, but the stator and regulator module are grounded to the engine thru their mounting surface. The regulator module therefore should not be removed and mounted at some remote location. This is a **negative ground circuit**. Connect ground strap from negative post of battery to starting motor flange, or good clean grounding surface on engine.

FLYWHEEL ALTERNATOR SERVICE PROCEDURE:

PRELIMINARY TESTS

1. **Visual Inspection** should be made to eliminate conditions that may be interpreted as a defected alternator. Examine leads for broken or loose connections, and make sure modules are securely mounted. The **regulator module** must be mounted to a metal surface for grounding purposes, (Test 5.0) while the **rectifier module**, although insulated from ground, should be securely mounted for heat dissipation. The mounting surfaces must clean and free of contaminants, oil, grease, etc.
2. **Check Battery**. Use an automotive battery in good condition, fully charged and with clean, tight terminal connections.
3. **Check Ammeter**. Be certain the ammeter is functioning correctly. Amperage output is regulated by engine speed. the **maximum amperage** output for Model W4-1770 is:

Maximum RPM	10 AMP System	25 AMP System
3000	9.5 amps	22 amps

When assured that the problem is with the alternator, follow the tests outlined in 'Trouble Shooting'.

TROUBLE SHOOTING

FLYWHEEL ALTERNATOR 12 VOLT - 10 AMP and 25 AMP Systems

Trouble Shooting Procedure is a guide showing methods of testing the charging components. The following chart of **Tests 1.0 to 4.1** are with the **engine running**, and substituting known good components in place of suspected faulty components. **Static Tests 5.0** thru **7.2**, following the running tests, are more conclusive but some test require special Wisconsin Test Lights.

Problem: Battery Overcharge	Possible Cause & Remedy
Test 1.0 Engine not running check battery with DC Voltmeter. 1.1 If voltage is greater than 13.5 volts 1.2 With engine running at full RPM, check battery voltage with DC Voltmeter. 1.3 If the charge increases beyond 13.5 volts. 1.4 If the charge remains under 13.5 volts.	1.1 Place 12 volt light bulb or carbon pile across battery to reduce voltage to below 13.5 volts. 1.3 Faulty regulator. Replace, —static check regulator per Test No. 5.1. 1.4 Alternator functioning properly. Check battery condition.

Problem: Low/No Charge	Possible Cause & Remedy
Test 2.0 Proceed with Test 1.0 and 1.1. It is necessary to slightly discharge battery to make system work. 2.1 With engine running at full RPM, check battery voltage with DC Voltmeter. 2.2 If the charge rate increases — 2.3 If system does not charge — 2.4 If the charge rate increased with regulator disconnected. 2.5 If the charge rate does not increase with regulator disconnected.	2.2 Alternator functioning properly. Battery was fully charged. 2.3 Operate engine with regulator disconnected (continue with Test 2.4). 2.4 Regulator was at fault. Replace regulator module, —static check regulator per Test No. 5.1. 2.5 Regulator not at fault. Check Rectifier per Test 3.0, 3.1 or static check per Test 6.0.

Problem: Low/No Charge	Possible Cause & Remedy
Test 3.0 Test conditions and procedure the same as 1.0 and 1.1. It is necessary to slightly discharge battery to make system work. 3.1 Plug new Rectifier in system. Run engine at full RPM. 3.2 If the charge rate increases with new rectifier in system. 3.3 If the charge rate does not increase with new Rectifier—	3.2 Rectifier module was at fault. Permanently install new rectifier module. 3.3 Rectifier not at fault. Check Stator per Test 4.0.

Problem: Low/No Charge	Possible Cause & Remedy
Test 4.0 With engine stopped, unplug all connectors between modules and stator. Start engine and run at 2400 RPM. With AC voltmeter check voltage between each of the black stator leads and ground. 4.1 If one of the two voltages is zero or they are over 10% apart—	4.1 The stator is defective and should be replaced. Static check stator per Tests 7.0, 7.1, 7.2.

FLYWHEEL ALTERNATOR COMPONENTS


STATIC TESTS

The following test equipment is required:

DF 83 Analyzer - Wisconsin Part, Fig. 46.

DF 81 Flashlite Tester - Wisconsin Part, Fig. 46.

VOLT-OHM-MILLIAMMETER Simpson 260 or equal.



The DF 83 Analyzer was developed for testing the solid state ignition and flywheel alternator components as furnished on *Wisconsin* engines. It is very efficiently and economically powered by four transistor radio type 9 volt batteries. The DF 81 Flashlite Tester is used primarily for checking continuity.

REGULATOR TESTS

Test 5.0 REGULATOR GROUND

The YJ60 Regulator module must be mounted to a metal surface for grounding purposes. Check for continuity with a VOM (R x 1 scale) or test light.

TESTER RED LEAD	TESTER BLACK LEAD	RESULT
To Regulator Body	To Ground	DF 83 - Light On DF 81 - Light On VOM - Continuity

Test 5.1 REGULATOR STATIC CHECK

This test is an alternative or in addition to running tests 2.3 and 2.4 (omitting regulator). The *DF 83* Analyzer is used.

YJ 60 REGULATOR

NOTE: Module is *defective* if light indication is *not as shown*.

TEST NO.	ANALYZER RED LEAD TO:	ANALYZER BLACK LEAD TO:	ANALYZER WHITE LEAD TO:	LIGHT INDICATION
1	Module Base Plate	Module Red Lead	—	OFF
2	Module Red Lead	Module Base Plate	—	OFF
3	Module Red Lead	Module Base Plate	Module Black Lead Then Remove	On And Remain On




Fig. 46

RECTIFIER TESTS

YJ 68 RECTIFIER (using VOM equipment)


Test 6.0 RECTIFIER STATIC CHECK

The diodes in the Rectifier module can be checked with any continuity device such as the DF 83 analyzer, DF 81 Flashlite or VOM. Since various testing devices will differ in their operation, it should be noted in the following three Rectifier test charts that the results in tests 1 and 2 should always be opposite to the results of tests 3 and 4.

YJ 68 RECTIFIER (using DF 83 Analyzer)

NOTE: Module is *defective* if light indication is *not* as shown.

TEST NO.	ANALYZER RED LEAD TO:	ANALYZER BLACK LEAD TO:	ANALYZER WHITE LEAD TO:	LIGHT INDICATION
1	Module White Lead	Either Module Black Lead	—	OFF
2	Module White Lead	Other Module Black Lead	—	OFF
3	Either Module Black Lead	Module White Lead	—	ON
4	Other Module Black Lead	Module White Lead	—	ON



YJ 68 RECTIFIER (using DF 81 Flashlite)

TEST NO.	TESTER RED LEAD TO:	TESTER BLACK LEAD TO:	LIGHT INDICATION
1	Module White Lead	Either Module Black Lead	ON
2	Module White Lead	Other Module Black Lead	ON
3	Either Module Black Lead	Module White Lead	OFF
4	Other Module Black Lead	Module White Lead	OFF

NOTE: Continuity shall be in one direction only. If readings are not as indicated, replace module.

TEST NO.	VOM RED LEAD TO:	VOM BLACK LEAD TO:	METER INDICATION
1	Module White Lead	Either Module Black Lead	No Continuity
2	Module White Lead	Other Module Black Lead	No Continuity
3	Either Module Black Lead	Module White Lead	Continuity
4	Other Module Black Lead	Module White Lead	Continuity

STATOR TESTS

YB 81, 10 amp STATOR YB 82, 25 amp STATOR

The continuity tests for stators is not a 100% method of checking. However, if the stator fails the continuity tests, it is definitely defective. If it passes the tests but all other components have also checked out O.K., the stator may be the defective part of the system and should be replaced. Test can be made with Stator on engine.



Test 7.0 STATOR GROUND

Like the Regulator, the YB 81 and YB 82 Stators must be grounded. Stator ground can be checked with any type continuity device.

TEST NO.	TESTER RED LEAD	TESTER BLACK LEAD	RESULT
1	To Stator Black Lead	To Ground	DF 83 - Light On DF 81 - Light On VOM - Continuity
2	To Other Black Lead	To Ground	


Test 7.1 STATOR CONTINUITY

This test should be performed after 7.0 stator ground test. Use continuity equipment such as DF 81 Flashlite or VOM. **Results other than specified indicate a defective stator.**

TEST NO.	TESTER RED LEAD	TESTER BLACK LEAD	RESULT
1	To Ground	To Stator Red Lead	DF 81 - Light On VOM - Continuity
2	To Ground	To Stator Black Lead	
3	To Ground	To Other Black Lead	

Test 7.2 CONTINUITY with DF 83 Analyzer

TEST NO.	ANALYZER RED LEAD TO:	ANALYZER BLACK LEAD TO:	ANALYZER WHITE LEAD TO:	LIGHT INDICATION
1	Stator Black Lead	Ground	—	ON
2	Stator Other Black Lead	Ground	—	ON
3	Ground	Stator Red Lead	—	ON
4	Ground	Stator Black Lead	—	ON
5	Ground	Stator Other Black Lead	—	ON



If light indication is other than shown, stator is defective. If stator checks out good, perform voltage test 7.3.

Test 7.3 STATOR RUNNING VOLTAGE

With the engine stopped, unplug all connectors between modules and stator. Start the engine and run at operating speed. Perform the following tests with an AC voltmeter:

TEST NO.	METER RED LEAD	METER BLACK LEAD	STATOR DEFECTIVE IF:
1	To Stator Black Lead	To Ground	Either Reading is 0 or Readings Vary more than 10%
2	To Other Stator Black Lead	To Ground	

BELT DRIVEN ALTERNATOR

The **12 volt - 37 Amp** Automotive type Alternator is optionally available in place of the Flywheel Alternator. No maintenance or adjustments are required other than periodically checking for loose, broken or dirty wire-terminal connections, and for proper drive belt tension. Bearings are pre-lubricated, no additional lubrication is necessary. The Regulator is an all electronic transistorized device, therefore no mechanical contacts or relay adjustments are necessary for voltage regulation.

The alternator is wired into the engine electrical system per Fig. 47.

IMPORTANT


This is a **Negative Ground** system. Charging components will be damaged if grounded wrong in connecting or jumping batteries.

Caution: Handle battery carefully to prevent acid burns. Avoid sparks near battery - gas given off by battery is explosive.

PRECAUTIONS to be exercised in the use of belt driven alternator:

1. Observe proper polarity when installing battery; negative battery terminal must be grounded. Reverse polarity will destroy the rectifier diodes in alternator.
2. As a precautionary measure, disconnect ground battery terminal when charging battery in vehicle. Connecting charger in reverse will destroy the rectifier diodes in the alternator.
3. **Do Not**, under any circumstances, short the field terminal of the alternator to ground, as permanent damage to the regulator may occur.
4. **Do Not**, remove the alternator from the vehicle without first disconnecting the grounded battery cable.
5. **Do Not**, operate engine with battery disconnected, or disconnect the alternator output lead while the alternator is operating, as damping effect of the battery will be lost. The voltage will rise to an extreme value and permanent damage to the regulator may occur.
6. **Do Not**, disconnect the voltage regulator while the alternator is operating, because the large voltage transient that occurs when disconnection takes place may damage the regulator.
7. **Caution:** Output wires from Alternator to Ammeter, and from Ammeter to battery terminal on starting solenoid must be of sufficient size for charging 37 amps. Use No. 10 gage stranded wire, or larger.

Fig. 47, WIRING DIAGRAM
ELECTRICAL SYSTEM
WITH
BELT DRIVEN ALTERNATOR
AND
SOLENOID STARTING



30 AMP FLYWHEEL ALTERNATOR

An improved 30 amp flywheel alternator system is now available as an option on VG4D engines. This improved 30 amp system is capable of higher output at lower engine speeds over the 25 amp flywheel alternator system.

This new 30 amp system can be easily recognized by the single regulator-rectifier module. The combination regulator-rectifier (YJ70) is mounted to the cylinder shroud on the VG4D. The YJ70 must be securely mounted to a location that will allow cooling of the unit.

In addition to a new style regulator-rectifier, a new stator (YB84) is used for this 30 amp system. Also, the magnet ring in the flywheel is different than the 25 amp system. In order to change a VG4D from the 25 amp system to this improved 30 amp system, the regulator-rectifier, stator, flywheel, wiring and cylinder shroud must be changed.

30 AMP FLYWHEEL ALTERNATOR TESTING

When testing a charging system which uses the YJ-70 rectifier-regulator module, the following items should be checked:

1. That the charging system is properly wired.
2. That all connections are clean and tight.
3. That the battery is in good condition.

The testing should begin by testing the A.C. voltage output of the stator where the 2 leads attach to the YJ-70. Disconnect the stator leads from the YJ-70 and hook them up to a volt-ohm meter. Use the A.C. voltage scale and the reading should be between 20 and 50 volts A.C. depending upon the engine rpm. (The faster the engine speed, the higher the A.C. voltage should be.) This test checks the stator and magnet ring. If the charging system passes all the previously mentioned checks, then the YJ-70 module can be checked as shown below. Use a good quality ohm meter. All readings are done on the RX100 scale. **Do not attempt to use the DF83 analyzer or any other type continuity tester.**

Ohmmeter Leads	Module Terminals	Components Under Test and Indication
1. Neg. (-) → Pos. (+) →	B+ Case	Diode Assembly Insulator, Power SCR's. Meter should indicate no continuity. (Infinity)
2. Neg. (-) → Pos. (+) →	B+ Each AC Terminal	Power Diode Forward Bias Test. Meter should indicate continuity but should not indicate a complete short-circuit. (Some Resistance)
3. Pos. (+) → Neg. (-) →	B+ Case	Regulator Control Circuitry. Meter should indicate no less than 7500 ohms and may read as high as approximately 30,000 ohms.
4. Pos. (+) → Neg. (-) →	Case Each AC Terminal	Power SCR's. Meter should indicate no Continuity. (Infinity)
5. Pos. (+) → Neg. (-) →	B+ Each AC Terminal	Power diode reverse bias test. No continuity. A very high resistance (50,000 - 1,000,000 ohms) may be observed if measured on the high resistance scale of an Ohmmeter.

SERVICE INSTRUCTIONS

DESCRIPTION

The Zenith 87-Series is a horizontal carburetor with a concentric fuel bowl. It is a "balanced" carburetor, because all air for fuel chamber and metering well ventilation and idling must come through the air cleaner. Air cleaner restrictions have a minimum influence on the fuel-air ratio when a carburetor is thus "balanced".

The main jet and discharge jet are centrally located. The metering well which completely surrounds the discharge jet is in the center of the fuel bowl assembly. This construction permits extremely high angle operation in any direction.

The venturi, which is part of the throttle body casting, measures the volume of air that passes through the carburetor. In selecting the venturi size, the smallest size that will permit full power development should be used.




Fig. 1 FUEL SUPPLY SYSTEM

OPERATION**FUEL SUPPLY SYSTEM (Fig. 1)**

Fuel under normal pressure entering the float chamber through the fuel valve seat is controlled by the twin float which, moving on its axle, closes the needle valve when the fuel reaches the proper level in the bowl.

IDLE SYSTEM (Fig. 2)

At idling speeds the throttle plate is almost closed, thus a very high suction exists at the edge of the throttle plate where the idle discharge holes are located. All fuel for idling and part throttle operation is supplied through the




Fig. 2 IDLE SYSTEM

main jet. Fuel from the float chamber flows through the main jet into the metering well. Fuel for idling is drawn from this well through the calibration, or metering orifice, in the center of the idling jet. As the fuel reaches the idling channel it is mixed with air which is admitted through a calibrated orifice in the channel from the inside of the air intake to form an emulsion. This emulsion is discharged into the air stream, to form the idling mixture, through two holes one of which is controlled by the idle adjusting needle. Turning the adjusting needle counter-clockwise (out) permits more of the emulsion to reach the air stream and make the idling mixture richer while turning the needle in (clockwise) cuts off the amount of the emulsion reaching the air stream and makes the mixture leaner.

HIGH SPEED SYSTEM (Fig. 3)

As the throttle is opened, the suction on the idling system diminishes, but the increased volume of air entering the engine through the venturi creates sufficient vacuum (suction) on the discharge jet to draw an emulsion of fuel and air from the metering well which receives its fuel from the main jet and its air from the well vent. The flow characteristics of the discharge jet are influenced by the size, location, and number of holes in the sides of that part of the jet which is in the metering well, as well as by




Fig. 3 HIGH SPEED SYSTEM

the sizes of the discharge jet orifice, the size of the main jet, and the size of the well vent. The well vent is located in the air intake and permits air to enter the top of the metering well around the outside of the discharge jet. The flow of fuel through the main jet is controlled by the size of main jet opening.

CHOKE SYSTEM (Fig. 4)

Starting a cold engine requires a much richer mixture of fuel and air. Moving the choke lever to close the choke plate restricts the air entering the carburetor (except at the pitot tube, Fig. 1, to the bowl vent) and increases the suction on the idling system which makes the mixture richer.

STARTING THE ENGINE

Before cranking the engine, the carburetor throttle should be opened a little to expose both idle discharge holes to suction. The choke should be fully closed until the engine starts, then opened a little to prevent stalling from being over-choke'd, then when the engine is fully warmed up the choke can be returned to wide open position and the throttle closed to the idling position.

ADJUSTMENTS

Adjust the throttle stop screw to obtain the desired idling speed by turning screw in (clockwise) to increase speed and out (counter-clockwise) to decrease engine speed.

Adjust the idle adjusting needle to obtain smooth idling of the engine at idling speed. Turn the needle out (counter-clockwise) to make the mixture richer, and in (clockwise) to make it leaner.




Fig. 4 CHOKE SYSTEM

SERVICE AND REPAIR PROCEDURE

IDENTIFY CARBURETOR

Check the numbers on the metal identification disc pinned to the top of the throttle body or indented in it. The plain number is the Zenith assembly number, the number with the letter "L" pre-fixed to it is Wis-Con Total Power's part number for the complete assembly.

DISASSEMBLY

SEPARATE CARBURETOR BODIES

Remove the three bowl assembly screws (45, 46) and separate fuel bowl (39) from throttle body (26).

DISASSEMBLE FUEL BOWL

1. Remove the main jet plug (43) and fibre washer (42), using a 9/16" open end wrench.
2. Remove the main jet (41) and fibre washer (40), using Zenith Tool No. C161-83 main jet wrench.
3. Remove the Idle Jet (38), using a small screwdriver.
4. Remove the bowl drain plug (44).

DISASSEMBLE THROTTLE BODY

1. Remove the float axle (35) by pressing against the end with the blade of a screwdriver.
2. Remove the float (36).
3. Remove the fuel valve needle (31), using the fingers.
4. Remove the fuel bowl to throttle body gasket (37).
5. Remove the main discharge jet (32), using a small screwdriver.
6. Remove the fuel valve seat (31) and fibre washer (30), using Zenith Tool No. C161-85.
7. Remove the idle adjusting needle (17) and spring (18).

CLEANING

Thoroughly clean all metal parts in Bendix Metalclene or Speedclene and rinse in cleaning solvent. Blow out all passages in throttle body and fuel bowl with reduced air pressure. Be sure all carbon deposits have been removed from throttle bore and idle discharge holes. Reverse the flow of compressed air through all passages to insure the removal of all dirt. **NEVER USE A DRILL OR WIRE TO CLEAN OUT JETS OR IDLE HOLES.**

INSPECTION OF PARTS

1. Float Assembly – Replace if loaded with gasoline, damaged or if float axle bearing is worn excessively. Inspect float lever for wear at point of contact with fuel valve needle. Replace if wear is excessive.
2. Float Axle – Replace if any wear has occurred on the bearing surface.
3. Fuel Valve (Needle & Seat) Assembly – Replace as a complete unit. Wear of any of these parts can seriously affect the operation of the float.
4. Idle Adjusting Needle – Inspect tapered end of the needle to make sure it is smooth and free of grooves. Replace if pitted or grooved.
5. Gaskets, Seal and Retainer – Replace all gaskets, throttle shaft seal and retainer each time the carburetor is overhauled.
6. Check Specifications. Verify the correctness of the following parts. Numbers will be found on the parts. Main Jet, Idling Jet and Fuel Valve.

REASSEMBLY

ASSEMBLY OF THROTTLE BODY

1. Install the fuel valve seat (31) and fibre washer (30), using Zenith Tool No. C161-85.
2. Install the main discharge jet (32), using a small screwdriver.
3. Install fuel valve needle in seat (31), followed by float (36) and float axle (35). NOTE: Insert tapered end of float axle (35) into float bracket on side opposite slot and push through the other side. Press float axle (35) into slotted side until the axle is centered in bracket.

4. FLOAT SETTING

- a. **Fuel Level.** Check position of float assembly (36), for correct measurement to obtain proper fuel level by using a depth gage. NOTE: Do not bend, twist, or apply pressure on the float body.
 - b. With bowl cover assembly (26) in an inverted position, viewed from free end of float (36), the float body must be centered and at right angles to the machined surface. The float setting is measured from the machined surface (no gasket) of float bowl cover to top side of float body at highest point. This measurement should be 31/32", plus or minus 1/32".
 - c. **Bending Float Lever.** To increase or decrease distance between float body (36) and machined surface (26) use long nosed pliers and bend lever close to float body. NOTE: Replace with new float if position is off more than 1/16".
5. Install throttle body to fuel bowl assembly gasket (37) on machined surface of throttle body (26).
 6. Install idle adjusting needle (17) and spring (18). Screw needle IN (clockwise) until it seats lightly against the idle discharge hole, then back it out 1 1/2 turns as a preliminary idle adjustment.

REASSEMBLE FUEL BOWL

1. Install the main jet (41) and fibre washer (40), using Zenith Tool No. C161-83 main jet wrench.
2. Install the main jet hex plug (43) and fibre washer (42), using a 9/16" open end wrench.
3. Install the idle jet (38), using a small screwdriver.
4. Install the bowl drain plug (44).

REASSEMBLE CARBURETOR BODIES

Install the three bowl assembly screws (45, 46) through the fuel bowl and into the throttle body and draw down firmly and evenly.

SPECIAL TOOLS


The special tools recommended are:

1. C161-83 Main Jet Wrench.
2. C161-85 Fuel Valve Seat Wrench.

WICO MODEL XHG-4 MAGNETO

FOR WISCONSIN MODEL VG4D ENGINES

SERVICE INSTRUCTIONS



TIMING

The magneto is properly timed to the engine at the factory. If it becomes necessary to retime the magneto to the engine, refer to the diagram and instructions in the engine instruction book.

LUBRICATION

The only lubricating point in the magneto is the cam wiper felt (Ref. No. 19). This felt, which lubricates the breaker arm at point of contact with the cam, should be replaced whenever it is necessary to replace the breaker contacts.

IMPORTANT

Incorrectly adjusted spark plug gaps cause magneto failure more frequently than any other condition.

Spark plugs should be inspected at frequent intervals, the size of the gap should be carefully checked and adjusted and the plugs thoroughly cleaned.

All oil, grease, and dirt should frequently be wiped off the magneto, lead wires, and spark plug insulators. Keeping these parts clean and the spark plugs properly adjusted will improve the engine performance and at the same time will prolong the life of the magneto.

DISTRIBUTOR CAP AND ARM

The distributor cap (Ref. No. 43) may be removed by loosening the 4 screws which hold it in place.

After the cap has been removed, the distributor arm (Ref. No. 57) may be pulled off the bridge. When replacing the arm make sure the timing marks on the distributor arm and the pinion gear are in line.

BREAKER CONTACTS — REPLACEMENT AND ADJUSTMENT

The breaker contacts should be adjusted to .015" when fully opened. To adjust the contacts, loosen the two clamp screws (Ref. No. 44) enough so that the contact plate can be moved.

Insert the end of a small screwdriver in the adjusting slot and open or close the contacts by moving the plate until the opening is .015", measuring with a feeler gauge of that thickness, tighten the two clamp screws.

To replace the contacts remove the breaker spring clamp screw

(Ref. No. 48), the breaker arm lock and washer, (Ref. No. 14) and (Ref. No. 18), then lift the breaker arm from its pivot. Remove the spacing washer and the two breaker plate clamp screws (Ref. No. 44). The breaker plate can then be removed.

If the contacts need replacing it is recommended that both the fixed contact and the breaker arm be replaced at the same time, using replacement breaker set (Ref. No. 46).

After assembly, the contacts should be adjusted as described in *Breaker Contacts* paragraph. The contacts should be kept clean at all times. Lacquer thinner is an ideal cleaner for this purpose. Use WICO tool S-5449, to adjust the alignment of the contacts so that both surfaces meet squarely.

CONDENSER

To remove the condenser (Ref. No. 35), first disconnect the condenser lead by removing the breaker arm spring screw (Ref. No. 48), then remove the two condenser clamp screws (Ref. No. 22), and the condenser clamp (Ref. No. 30). When replacing the condenser make sure it is properly placed between the two locating bosses and that the clamp screws are securely tightened.

COIL AND COIL CORE

The coil and coil core must be removed from the magneto housing as a unit. After the distributor cap and distributor arm have been removed, and the primary wire disconnected from the breaker arm spring terminal by removing screw (Ref. No. 48), take out the two coil core clamp screws (Ref. No. 21), and remove the clamps (Ref. No. 38). The coil and core can then be pulled from the housing. When replacing this group make sure that the bare primary wire is connected under the core clamp screw and that the insulated wire is connected to the breaker arm spring terminal.

REMOVAL OF COIL FROM CORE

The coil (Ref. No. 40) is held tight on the core (Ref. No. 29) by a spring wedge. It will be necessary to press against the coil core with considerable force to remove it from the coil. The coil should be supported in such a way that there is no danger of the primary of the coil being pushed out of the secondary.

MAGNETO SERVICE INSTRUCTIONS FAIRBANKS-MORSE TYPE FM-X4B7A

Y-97 Series

Wisconsin No. Y-97-S1 (With GD-103-1 DRIVE GEAR) FOR MODEL VG4D

GENERAL DESCRIPTION

Fairbanks-Morse Type FM-X4B7A Magneto is designed and engineered to provide quick easy starting and maximum dependability of operation with minimum service. The compact alnico magnetic rotor assures an intensely hot spark under most operating conditions.

SERVICE PROCEDURE

The first step in magneto field servicing is to examine the magneto for corroded high tension towers, broken wires, or high tension wires not pushed far enough into the magneto tower to make good contact.

Then test the ignition spark while engine is being cranked. If a strong spark is observed, the magneto is not the cause of engine malfunction. If no spark is seen, proceed with servicing magneto.

SERVICING BREAKER POINTS, FIG. 1

Remove the end cap cover, distributor rotor and the end cap. Then inspect the breaker points for pitting, oxidation and shorting. If points are worn or shorted, they should be replaced.

To remove the point set, take out the breaker arm terminal screw releasing the breaker arm spring, coil lead and condenser lead. Remove the fulcrum pin snap ring and slide the breaker arm off the fulcrum pin. Remove the contact support locking screws and lift off the contact support.

The installation of new points is the reverse of the removal. After the points have been installed, they should be adjusted to the correct clearance of 0.015 inch at high point of cam. Be sure the points are clean and bright before adjusting them. Insert a screwdriver in the slot of the support bracket and pivot it between the two small bosses on the bearing support until the desired clearance is obtained. Then clean the points again before sealing the magneto.




Fig. 1, BREAKER POINT ADJUSTMENT

FIELD SERVICE NOT RECOMMENDED

The cam wick, if dry or hard, should be replaced with a new factory impregnated wick. Other than this the magneto does not require field lubrication. No attempt should be made to oil or grease the magneto bearings. The magneto lubricant should be replaced only during the overhaul of the magneto by a Fairbanks-Morse authorized service station using recommended lubricant and factory engineered parts.

Coil and condenser replacement while simple are not recommended unless adequate test equipment is available. No attempt should be made to remove magnetic rotor from housing unless specific instructions for releasing the shaft are available.

INTERNAL TIMING, FIG. 2

If, for any reason, the magneto has been dismantled to the extent that the distributor gear has been removed the teeth must be properly meshed with those of the magnetic rotor gear upon reassembly. The gear teeth are marked to facilitate internal timing. The single marked tooth of the rotor gear must mesh between the two teeth of the distributor gear designated by the letter C.




Fig. 2, INTERNAL TIMING GEARS

TIMING THE MAGNETO TO THE ENGINE

If the magneto has been removed from the engine for servicing, the operator must follow the engine manufacturer's instructions for timing the magneto to the engine. Refer to 'Magneto Timing' in engine instruction manual. When installing the magneto on the engine, be sure the magneto is properly attached and that the housing to engine gasket is in good condition.

SPECIAL DRIVE GEAR, FIG. 3

The magneto is equipped with a special drive gear mounted directly on the impulse coupling. If it is necessary to replace the drive gear, special care must be exercised in reassembly. It is possible to be off 180° in timing if gear is improperly mounted.

Assemble gear as follows: Remove magneto end cap cover and turn distributor rotor until it is in firing position for No. 1 cylinder. Retain rotor in this position and fit the drive gear to the impulse coupling lugs so that the prick punch mark on front of gear is located as shown.




Fig. 3, DRIVE GEAR MARKING AND ASSEMBLY

SOLID STATE IGNITION DISTRIBUTORS

Many new Wisconsin multi-cylinder engines are now being equipped with a solid state ignition distributor. Externally the new solid state ignition distributors are similar in appearance to a conventional point ignition distributor. Internally the major differences are:

1. Distributor cam which opens ignition points has been replaced with a magnet assembly.
2. Ignition points have been replaced with a "Hall effect type" electronic module.

This solid state ignition distributor uses two primary wire leads which attach to the ignition coil. The black or blue lead connects the negative (-) terminal of the ignition coil while the red lead connects to the positive (+) side of the ignition coil.

NOTE: The same Wisconsin coil is used on the solid state and point ignition systems.

TROUBLESHOOTING

The following steps should be performed if the engine's ignition system appears to be not operating properly:

1. Visually inspect plug wires, coil wire, distributor cap and rotor. Replace any components that show deterioration. It is especially important that the cap and plug wires be in good condition, free of oil, grease and moisture.
2. Check for loose or poor connections in ignition circuit. Check battery terminals for corrosion and loose connections.
3. Check battery voltage with engine off. It should be 12 to 15 volts.

If the above items have been checked and found to be proper and the engine's distributor is believed to be faulty, the distributor should be tested.

NOTE: Ignition timing adjustment specifications and procedures for the solid state ignition systems are the same as the corresponding point ignition distributor. An automotive type timing light should be used to check and adjust ignition timing.

TESTING

Testing can be done either with a voltmeter or a 12 volt test light.

VOLT METER TESTING

1. Connect the positive (+) lead of a voltmeter to the negative (-) side of the ignition coil. Ground the negative (-) lead of the voltmeter. Set the voltmeter to DC volts on at least a 15 volt scale.
2. Disconnect the high voltage wire from the center of the distributor cap and ground it to the engine block or chassis.
3. Crank engine.
4. The voltmeter should fluctuate from a range of 1 to 2 volts to a range of 10 to 12 volts as the engine is cranked.
NOTE: On some voltmeters the needle will appear to bounce between 1 and 12 volts.
5. If the voltmeter does not fluctuate, one of the following problems exist:

- a. If the voltmeter shows a constant 0 reading, there is an open circuit somewhere in the primary ignition circuit.
- b. If the voltmeter shows a constant voltage in the 1.0 to 3.5 volt range, the electronic module is shorted out.
- c. If the voltmeter shows a constant voltage equal to the battery voltage, the electronic module has an open circuit and requires replacement.

12 VOLT TEST LIGHT

1. Connect the test light between the positive (+) side of the ignition coil and ground. With the ignition switch in the "on" position the light should light.
NOTE: If there is no voltage present at the positive side of the coil, recheck the circuit from the battery through the ignition switch to the coil.
2. Disconnect the black primary lead going between the ignition coil negative (-) terminal and the distributor. Connect the test light to the negative (-) terminal of the ignition coil. Turn the ignition switch on - the test light should light, if not the ignition coil primary winding is open and the coil should be replaced.

Reconnect the black primary lead of the distributor to the negative (-) terminal of the ignition coil. Connect the test light again to the negative terminal of the ignition coil.

3. Disconnect the high voltage wire from the center of the distributor cap and ground to the engine.
4. Crank the engine.
5. The test light should flicker as the engine is cranked.
6. If the light does not flicker then the distributor electronic module is faulty.

NOTES

To avoid damage to the distributor components the following conditions must be avoided:

1. REVERSE POLARITY - **Do not** reverse the battery cables - (this distributor is for negative ground systems only) or the ignition coil wires. Black coil lead to negative terminal of the coil; red lead to positive terminal of the coil.

Some early production distributors have a blue lead instead of a black lead for the negative coil lead.

2. VOLTAGE SURGES - **Do not** operate the engine with the battery disconnected. Insure all electrical connections are made properly. Avoid using switches on the engine which cause excessive arcing.
3. Disconnect the ground (negative) cable when charging the battery.
4. JUMP STARTING - Only use another 12 volt battery for jump starting - be sure battery polarity is correct (positive to positive, negative to negative.)

NOTE: A HIGH AMPERAGE BOOST CHARGER CAN DAMAGE THE SOLID STATE COMPONENTS WITHIN THE DISTRIBUTOR.

ENGINE MAINTENANCE SCHEDULE	Page Ref.	Daily	Weekly or 50 hrs.	100 hrs.	250 hrs.	Seasonally or 500 hrs.
CHECK OIL LEVEL. Add to full mark - Do not overfill.	5					
CHECK AIR CLEANER. Shake out accumulated dirt from dry element cleaner - Maintain oil level in oil bath type cleaner.	7					
CLEAN AIR INTAKE SCREEN. Clean cooling fins if necessary.	9					
CLEAN AIR FILTER ELEMENT. Dry Element and Oil Bath types.	7		●			
CHANGE CRANKCASE OIL. Use grade and classification of oil recommended. In adverse conditions change oil every 50 hours of operation.	5			●		
REPLACE OIL FILTER every oil change. Replacement Filter RV-40.	8			●		
CLEAN CRANKCASE BREATHER CAP.	8			●		
CHECK COMPRESSION. Pressure should not vary more than 10 p.s.i. between cylinders. Remove head - clean out carbon deposits. Reseat valves if necessary	21					
INSPECT SPARK PLUGS and BREAKER POINTS. Replace if necessary and regop to specification.	9,10					
INSPECT FUEL FILTER. Clean filter screen and glass bowl.	8					
LUBRICATE DISTRIBUTOR CAM and breaker arm pivot.	8					
INSPECT COOLING SYSTEM. Remove shrouding and scrape off dirt from between fins, around cylinders and from shrouding.	9				●	
INSPECT STARTING MOTOR. Check for loose mounting and cable connections.	9					
CHANGE OIL IN CLUTCH and REDUCTION GEAR HOUSINGS.	6					

TORQUE SPECIFICATIONS FOR MACHINE HARDWARE (dry)

Special Torque Values

TORQUE Foot Pounds	PART
28-32	CONNECTING ROD
56-62	CYLINDER BLOCK
28-32	CYLINDER HEAD
8-11	OIL PAN (ENGINE BASE)
16-18	GEAR COVER
32-35	MANIFOLD (INTAKE & EXHAUST)
25-30	MAIN BEARING PLATE
95-110	FLYWHEEL NUT
25-30	SPARK PLUG

General Torque Values - Maximum Foot Pounds

MARKINGS ON BOLT HEADS	SAE GRADE 1 or 2	SAE GRADE 5	SAE GRADE 8
			
SIZE	Foot Pounds Torque	Foot Pounds Torque	Foot Pounds Torque
10-24	2.3	3.5	5
10-32	2.5	4	5.6
1/4-20	6	11	12
1/4-28	7	13	15
5/16-18	13	21	25
5/16-24	14	23	30
3/8-16	23	38	50
3/8-24	26	40	60
7/16-14	37	55	85
7/16-20	41	60	95
1/2-13	57	85	125
1/2-20	64	95	140

Caution: Tightening into aluminum usually requires less torque. Increase Chart Torque Values by 20% if lubricant is used.

SERVICE AND PARTS
Available from your Authorized
WIS-CON TOTAL POWER
Service Center



HEADQUARTERS:

3409 Democrat Road P.O. Box 181160 Memphis, Tennessee 38181
Phone: (901) 365-3600 TELEX: 462-1058 (ITT) FAX NO: (901) 369-4050

EUR PEAN:

Rue Joseph Deflandre, 13 B-4053 Chaudfontaine (Liege) Belgium
Phone: (32) (41) 675320 TELEX: 42631 TDY TP B FAX NO: (32) (41) 677987